





2011 AUTO SPARE PARTS

PARTS-MALL

PRODUCT GUIDE Vol.2

PARTS MALL CORPORATION!

**YOU WILL ACCESS TO EVERY SINGLE AUTO PARTS
THROUGH PARTS MALL**



Since the foundation in 1998, through over 100% of annual growth and strong cooperation with many customers over the world, we have stood up as a key model company representing auto parts suppliers in Korea. We have been doing our best in all different parts of business and are very confident about our level of quality, price, delivery, supply rate, information and service.

We are declaring our 2nd round of business challenge with our own brand, "Parts Mall" items. We have currently initiated with small range of items such as Filters, Gaskets, Shock Absorbers, Brake pad sets, Brake shoe Assembly, Water Pumps and Spark Plug Cables, however, will cover all Fast Moving Items by our own brand in nears future.

We will be with you all the time and your future is our future.

Thanks and Best Regards,

C o n t e n t s . . .

CAR-DEX - SUSPENSION PARTS

ARM ASSY - SUSPENSION	_____
BALL JOINT - SUSPENSION ARM	_____
BUSHING - SUSPENSION ARM / CROSSMEMBER MTG	_____
END ASSY - TIE ROD / RACK	_____
LINK ASSY - STABILIZER / SUSPENSION	_____
INSULATOR ASSY - ENG MTG / TM MTG / STRUT MTG / OTHERS	_____
RUBBER - BUSH / HANGER / STOPPER / Etc.	_____
HOSE - RADIATOR IN/OUT	_____
BOOT - CV JOINT(+band) / BELLOWS - STEERING GEAR	_____
HOSE - OTHERS	_____

MX - PISTON

ALUMINUM TYPE	_____
ALFIN TYPE	_____

NT - COOLING & AIR CONDITIONING PARTS

RADIATOR	_____
CONDENSOR (KOREAN CAR)	_____
CONDENSOR (FOREIGN CAR)	_____
FAN & MOTOR	_____

POMAX - ELECTRICAL PARTS

ALTERNATER	_____
STARTER	_____
PULLY & SENSOR	_____



CAR-DEX

www.parts-mall.com

Suspension is very important section of automobile for stable and comfortable driving.

CAR-DEX is applicable to all Korean vehicles such as HYUNDAI, KIA, DAEWOO(CHEVROLTE),

SSANGYONG ranging from arm, link, bushing, tie rod end, ball joint, etc..with good quality and reasonable price.

CAR-DEX NO. INDEX

C **A** — **H** **0** **0** **1**

1 2 3 4

1. CAR-DEX INITIAL

2. PARTS NAME

CODE	PARTS NAME
A	ARM ASSY - SUSPENSION
J	BALL JOINT - SUSPENSION ARM
B	BUSHING - SUSPENSION ARM / CROSSMEMBER MTG
T	END ASSY - TIE ROD / RACK
L	LINK ASSY - STABILIZER / SUSPENSION
M	INSULATOR ASSY - ENG MTG / TM MTG / STRUT MTG / OTHERS
R	RUBBER - BUSH / HANGER / STOPPER / Etc.
H	HOSE - RADIATOR IN/OUT
W	BOOT - CV JOINT(+band) / BELLOWS - STEERING GEAR
Q	HOSE - OTHERS

3. CAR MAKERS

CODE	MAKER
H	HYUNDAI
K	KIA
D	GM DAEWOO
S	SSANGYONG
U	SAMSUNG
J	JAPANESE CAR

4. SERIAL NO.

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
ARM ASSY - SUSPENSION							
HYUNDAI							
ACCENT				94.04-99.10	L	ARM & BALL JOINT ASSY-LWR	CA-H001
				02.11-07.08	L	ARM COMPLETE-FR LWR LH	CA-H001
				94.04-99.10	R	ARM & BALL JOINT ASSY-LWR	CA-H002
				02.11-07.08	R	ARM COMPLETE-FR LWR RH	CA-H002
				94.04-07.08	L	ARM ASSY-TRAILING	CA-H401
				94.04-07.08	R	ARM ASSY-TRAILING	CA-H402
				94.04-07.08	FR	ARM ASSY-RR SUSPENSION	CA-H403
				94.04-07.08	RR	ARM ASSY-RR SUSPENSION	CA-H404
ACCENT 00MY				99.06~	L	ARM COMPLETE-LWR	CA-H036
				99.06~	R	ARM COMPLETE-LWR	CA-H037
				99.06~	L	ARM COMPLETE-TRAILING	CA-H410
				99.06~	R	ARM COMPLETE-TRAILING	CA-H411
				99.06~	RR/L	ARM ASSY-RR SUSPENSION	CA-H412
				99.06~	RR/R	ARM ASSY-RR SUSPENSION	CA-H413
				99.06-06.12	RR/L	ARM ASSY-RR SUSPENSION	CA-H422
				99.06-06.12	RR/R	ARM ASSY-RR SUSPENSION	CA-H423
ACCENT(INDIA)				99.06~	L	ARM COMPLETE-LWR	CA-H036
				99.06~	R	ARM COMPLETE-LWR	CA-H037
				99.06~	L	ARM COMPLETE-TRAILING	CA-H410
				99.06~	R	ARM COMPLETE-TRAILING	CA-H411
				99.06~	RR/L	ARM ASSY-RR SUSPENSION	CA-H412
				99.06~	FR/R	ARM ASSY-RR SUSPENSION	CA-H413
				99.06~	RR/L	ARM ASSY-RR SUSPENSION	CA-H422
				99.06~	RR/L	ARM ASSY-RR SUSPENSION	CA-H423
ATOS				97.08-07.01	L	ARM COMPLETE-LWR	CA-H003
				97.08-07.01	R	ARM COMPLETE-LWR	CA-H004
AVANTE	BETA		GASOLINE	96.04-96.07	L	ARM COMPLETE-LWR	CA-H034
				95.03-01.10	L	ARM COMPLETE-LWR	CA-H034
				96.04-96.07	R	ARM COMPLETE-LWR	CA-H035
	BETA BETA,ALPHA		GASOLINE	95.03-01.10	R	ARM COMPLETE-LWR	CA-H035
				95.03-01.10	L	COMPLETE-TRAILING ARM	CA-H415
BETA,ALPHA		GASOLINE	95.03-01.10	R	COMPLETE-TRAILING ARM	CA-H416	
AVANTE XD	BETA,G4EC		GASOLINE	00.03-07.02	L	ARM COMPLETE-LWR	CA-H005
				01.08-06.08	L	ARM COMPLETE-LWR	CA-H005
				01.08-06.08	R	ARM COMPLETE-LWR	CA-H006
	BETA,G4EC		GASOLINE	00.03-07.02	R	ARM COMPLETE-LWR	CA-H006
CENTENNIAL				92.09-08.11	L/R	ARM ASSY-LWR	CA-H414
CLICK	G4AE,G4AE,G4EC		GASOLINE	02.05~	L	ARM COMPLETE-LWR	CA-H046
	G4AE,G4AE,G4EC		GASOLINE	02.05~	R	ARM COMPLETE-LWR	CA-H047
COUPE	BETA		GASOLINE	96.04-96.07	L	ARM COMPLETE-LWR	CA-H034
				95.03-01.10	L	ARM COMPLETE-LWR	CA-H034
				96.04-96.07	R	ARM COMPLETE-LWR	CA-H035
	BETA BETA,ALPHA		GASOLINE	95.03-01.10	R	ARM COMPLETE-LWR	CA-H035
				95.03-01.10	L	COMPLETE-TRAILING ARM	CA-H415
				95.03-01.10	R	COMPLETE-TRAILING ARM	CA-H416
COUPE 01MY				02.07-06.08	L	ARM COMPLETE-LWR	CA-H005
				02.07-06.08	R	ARM COMPLETE-LWR	CA-H006
COUPE 01MY(JAPAN)				02.07-06.08	L	ARM COMPLETE-LWR	CA-H005
				02.07-06.08	R	ARM COMPLETE-LWR	CA-H006
COUPE 97MY	BETA		GASOLINE	96.04-96.07	L	ARM COMPLETE-LWR	CA-H034
				95.03-01.10	L	ARM COMPLETE-LWR	CA-H034
				96.04-96.07	R	ARM COMPLETE-LWR	CA-H035
	BETA BETA,ALPHA		GASOLINE	95.03-01.10	R	ARM COMPLETE-LWR	CA-H035
				95.03-01.10	L	COMPLETE-TRAILING ARM	CA-H415
				95.03-01.10	R	COMPLETE-TRAILING ARM	CA-H416
ECUUS	I4		GASOLINE	93.03-98.06	L/R	ARM & BUSH ASSY-SUSP LWR	CA-H414

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.		
ELANTRA	BETA BETA,G4EC		GASOLINE GASOLINE	92.09~05.01	L/R	ARM & BUSH ASSY-SUSP LWR	CA-H414		
				99.03~08.11	L/R	ARM ASSY-LWR	CA-H414		
				90.11~93.04	L	ARM & BALL JOINT ASSY-LWR	CA-H011		
				90.07~95.08	L	ARM & BALL JOINT ASSY-LWR	CA-H013		
				95.03~01.10	L	ARM COMPLETE-LWR	CA-H034		
				00.03~07.02	L	ARM COMPLETE-LWR	CA-H005		
				02.07~03.01	L	ARM COMPLETE-LWR	CA-H005		
				90.11~93.04	R	ARM & BALL JOINT ASSY-LWR	CA-H012		
				90.07~95.08	R	ARM & BALL JOINT ASSY-LWR	CA-H014		
				95.03~01.10	R	ARM COMPLETE-LWR	CA-H035		
				02.07~07.02	R	ARM COMPLETE-LWR	CA-H006		
				BETA BETA,G4EC	GASOLINE GASOLINE	95.03~01.10	R	ARM COMPLETE-LWR	CA-H035
				BETA,ALPHA	GASOLINE	02.07~07.02	R	ARM COMPLETE-LWR	CA-H006
				BETA,ALPHA	GASOLINE	95.03~01.10	L	COMPLETE-TRAILING ARM	CA-H415
BETA,ALPHA	GASOLINE	95.03~01.10	R	COMPLETE-TRAILING ARM	CA-H416				
ELANTRA 00MY	BETA,G4EC		GASOLINE	00.03~02.07	R	ARM COMPLETE-LWR	CA-H006		
ELANTRA 96MY	BETA		GASOLINE	95.03~01.10	L	ARM COMPLETE-LWR	CA-H034		
	BETA		GASOLINE	95.03~01.10	R	ARM COMPLETE-LWR	CA-H035		
	BETA,ALPHA		GASOLINE	95.03~01.10	L	COMPLETE-TRAILING ARM	CA-H415		
	BETA,ALPHA		GASOLINE	95.03~01.10	R	COMPLETE-TRAILING ARM	CA-H416		
ELANTRA(JAPAN)	BETA,G4EC		GASOLINE	00.03~02.07	R	ARM COMPLETE-LWR	CA-H006		
EXCEL				89.04~04.11	L	ARM & BALL JOINT ASSY-LWR	CA-H015		
				89.07~95.03	R	ARM & BALL JOINT ASSY-LWR	CA-H016		
GALLOPER				97.09~		ARM COMPLETE-IDLER	CA-H601		
				91.10~03.12		SHAFT-UPR ARM	CA-K205		
				91.10~03.12	L	ARM COMPLETE-UPR	CA-H214		
				91.10~03.12	R	ARM COMPLETE-UPR	CA-H215		
				91.10~04.11	L	ARM COMPLETE-IDLER	CA-H601		
				91.10~04.11		ARM ASSY-PITMAN	CA-H801		
GALLOPER INNOVATION				97.09~		ARM COMPLETE-IDLER	CA-H601		
				91.10~03.12		SHAFT-UPR ARM	CA-K205		
				91.10~03.12	L	ARM COMPLETE-UPR	CA-H214		
				91.10~03.12	R	ARM COMPLETE-UPR	CA-H215		
				92.02~		ARM ASSY-PITMAN	CA-H801		
GALLOPER2				97.09~		ARM COMPLETE-IDLER	CA-H601		
				91.10~03.12		SHAFT-UPR ARM	CA-K205		
				91.10~03.12	L	ARM COMPLETE-UPR	CA-H214		
				91.10~03.12	R	ARM COMPLETE-UPR	CA-H215		
				92.02~		ARM ASSY-PITMAN	CA-H801		
GETZ	G4AE,G4AE,G4EC		GASOLINE	02.05~	L	ARM COMPLETE-LWR	CA-H046		
	G4AE,G4AE,G4EC		GASOLINE	02.05~	R	ARM COMPLETE-LWR	CA-H047		
GRACE	D4BA,D4BF,L4CS		DIESEL	87.01~03.12	L	ARM COMPLETE-UPR	CA-H203		
				93.07~04.01	L	ARM COMPLETE-UPR	CA-H203		
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	L	ARM COMPLETE-UPR	CA-H203		
	D4BA,D4BF,L4CS		DIESEL	87.01~04.01	R	ARM COMPLETE-UPR	CA-H204		
				93.07~03.12	R	ARM COMPLETE-UPR	CA-H204		
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	R	ARM COMPLETE-UPR	CA-H204		
					L	ARM COMPLETE-LWR	CA-H017		
	D4BA,D4BF,L4CS		DIESEL	93.03~04.01	L	ARM COMPLETE-LWR	CA-H017		
				87.01~03.12	L	ARM COMPLETE-LWR	CA-H017		
	D4BA,D4BF,L4CS		DIESEL	93.03~04.01	R	ARM COMPLETE-LWR	CA-H018		
				94.07~96.02	R	ARM COMPLETE-LWR	CA-H018		
GRANDEUR				98.03~	L	ARM ASSY-FR UPR	CA-H201		
				98.03~	R	ARM ASSY-FR UPR	CA-H202		
				98.03~00.08	L	ARM COMPLETE-FR LWR	CA-H009		
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007		
				92.09~05.01	L	ARM & BALL JOINT ASSY-LWR	CA-H019		
				98.03~99.11	R	ARM COMPLETE-LWR	CA-H010		
				~00.08	R	ARM COMPLETE-FR LWR	CA-H010		
				00.08~06.01	R	ARM COMPLETE-LWR	CA-H008		
				04.08~	R	ARM ASSY-LWR.	CA-H008		
				92.09~05.01	R	ARM & BALL JOINT ASSY-LWR	CA-H020		
				98.03~	L	ARM ASSY-RR UPR	CA-H405		
				98.03~	R	ARM ASSY-RR UPR	CA-H406		

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.	
				98.03~		ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
GRANDEUR XG (JAPAN)				98.03~	L	ARM ASSY-FR UPR	CA-H201	
				98.03~	R	ARM ASSY-FR UPR	CA-H202	
				00.08~	L	ARM COMPLETE-FR LWR	CA-H007	
				00.08~	R	ARM COMPLETE-FR LWR	CA-H008	
				00.06~	L	ARM ASSY-RR UPR	CA-H405	
				98.03~		ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-TRAILING	CA-H408	
	GRANDEUR XG				98.03~	L	ARM ASSY-FR UPR	CA-H201
				98.03~	R	ARM ASSY-FR UPR	CA-H202	
				98.03~00.08	L	ARM COMPLETE-FR LWR	CA-H009	
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007	
				98.03~00.08	R	ARM COMPLETE-FR LWR	CA-H010	
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008	
				98.03~	L	ARM ASSY-RR UPR	CA-H405	
				98.03~	R	ARM ASSY-RR UPR	CA-H406	
				98.03~	CTR	ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
H-1 02MY		D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-UPR	CA-H209
		D4BB,D4BF,D4BH		DIESEL	96.11~02.01	L	ARM COMPLETE-UPR	CA-H211
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-UPR	CA-H210	
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	R	ARM COMPLETE-UPR	CA-H212	
	D4BB,D4BF,D4BH,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-LWR	CA-H032	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-LWR	CA-H033	
	H-1 04MY	D4BB,D4BF,L4CS,D4BH		DIESEL	03.12~07.12	L	ARM COMPLETE-UPR	CA-H209
D4BB,D4BF,L4CS,D4BH			DIESEL	03.12~07.12	R	ARM COMPLETE-UPR	CA-H210	
D4BB,D4BF,D4BH,D4BH			DIESEL	03.12~07.12	L	ARM COMPLETE-LWR	CA-H032	
D4BB,D4BF,L4CS,D4BH			DIESEL	03.12~07.12	R	ARM COMPLETE-LWR	CA-H033	
H-1 98MY		D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-UPR	CA-H209
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	L	ARM COMPLETE-UPR	CA-H211	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-UPR	CA-H210	
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	R	ARM COMPLETE-UPR	CA-H212	
	D4BB,D4BF,D4BH,D4BH		DIESEL	96.11~05.01	L	ARM COMPLETE-LWR	CA-H032	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~05.01	R	ARM COMPLETE-LWR	CA-H033	
	H-100 04MY	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	L	ARM COMPLETE-UPR	CA-H203
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	R	ARM COMPLETE-UPR	CA-H204	
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	L	ARM COMPLETE-LWR	CA-H024	
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	R	ARM COMPLETE-LWR	CA-H025	
H-100 93MY~97MY						L	ARM COMPLETE-UPR	CA-H205
					R	ARM COMPLETE-UPR	CA-H206	
				90.10~97.03		ARM ASSY-PITMAN	CA-H802	
				93.07~97.03		IDLER ARM & SUPPORT ASSY	CA-H602	
H-100(AU TRUCK)	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	L	ARM COMPLETE-UPR	CA-H203	
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	R	ARM COMPLETE-UPR	CA-H204	
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.09	L	ARM COMPLETE-LWR	CA-H024	
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.09	R	ARM COMPLETE-LWR	CA-H025	
	H-100(MINI BUS)				93.07~03.12	L	ARM COMPLETE-UPR	CA-H203
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	L	ARM COMPLETE-UPR	CA-H203	
				93.07~03.12	R	ARM COMPLETE-UPR	CA-H204	
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	R	ARM COMPLETE-UPR	CA-H204	
D4BA,D4BF,L4CS			DIESEL	93.03~03.12	L	ARM COMPLETE-LWR	CA-H017	
D4BA,D4BF,L4CS			DIESEL	93.03~03.12	R	ARM COMPLETE-LWR	CA-H018	
				94.07~96.02	R	ARM COMPLETE-LWR	CA-H018	
MARCIA					95.04~98.06	L	ARM COMPLETE-LWR	CA-H030
				95.01~04.01	L	ARM & BALL JOINT ASSY-LWR	CA-H030	
				95.01~98.06	R	ARM COMPLETE-LWR	CA-H031	
				95.01~04.01	R	ARM & BALL JOINT ASSY-LWR	CA-H031	
	PORTER				87.01~96.02	L	ARM COMPLETE-UPR	CA-H205
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~	L	ARM COMPLETE-UPR	CA-H203	

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
	D4BA,D4BB,D4BF,L4CS		DIESEL	87.01~96.02	R	ARM COMPLETE-UPR	CA-H206
				96.03~	R	ARM COMPLETE-UPR	CA-H204
				87.01~96.02	L	ARM COMPLETE-LWR	CA-H038
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~	L	ARM COMPLETE-LWR	CA-H024
				87.01~96.02	R	ARM COMPLETE-LWR	CA-H039
				96.03~	R	ARM COMPLETE-LWR	CA-H025
	D4BA,D4BB,D4BF,L4CS		DIESEL	90.10~97.03		ARM ASSY-PITMAN	CA-H802
				87.01~97.03		IDLER ARM & SUPPORT ASSY	CA-H602
	SANTA FE				00.03~	L	ARM COMPLETE-LWR
				00.03~	R	ARM COMPLETE-LWR	CA-H041
SANTA FE(JAPAN)				00.03~	L	ARM COMPLETE-LWR	CA-H040
				00.03~	R	ARM COMPLETE-LWR	CA-H041
SANTAMO				94.03~04.11	L	ARM COMPLETE-LWR	CA-K024
				96.01~04,11	R	ARM COMPLETE-LWR	CA-K025
				94.04~03.03	L	ARM ASSY-LWR	CA-K024
				99.04~03.03	R	ARM ASSY-LWR	CA-K025
SANTRO				99.03~07.01	L	ARM COMPLETE-LWR	CA-H003
SCOUPE				89.07~95.03	L	ARM & BALL JOINT ASSY-LWR	CA-H015
				89.07~95.03	R	ARM & BALL JOINT ASSY-LWR	CA-H016
				89.04~95.03	L	ARM COMPLETE-LWR	CA-H042
				89.04~95.03	R	ARM COMPLETE-LWR	CA-H043
SONATA				91.03~93.09	L	ARM & BALL JOINT ASSY-LWR	CA-H028
				93.03~94.09	L	ARM COMPLETE-LWR	CA-H026
				94.09~95.04	L	ARM COMPLETE-LWR	CA-H026
				93.04~95.04	L	ARM & BALL JOINT ASSY-LWR	CA-H026
				95.04~98.06	L	ARM COMPLETE-LWR	CA-H030
				95.01~95.09	L	ARM & BALL JOINT ASSY-LWR	CA-H030
				95.09~04.01	L	ARM & BALL JOINT ASSY-LWR	CA-H030
				88.06~93.09	R	ARM & BALL JOINT ASSY-LWR	CA-H029
				93.03~95.04	R	ARM COMPLETE-LWR	CA-H027
				93.04~95.04	R	ARM & BALL JOINT ASSY-LWR	CA-H027
				95.01~04.01	R	ARM COMPLETE-LWR	CA-H031
				92.09~08.11		ARM ASSY-LWR	CA-H414
				92.09~05.01		ARM & BUSH ASSY-SUSP LWR	CA-H414
				93.03~98.06		ARM & BUSH ASSY-RR SUSP LWR	CA-H414
SONATA (INDIA)				98.03~	L	ARM ASSY-FR UPR	CA-H201
				98.03~	R	ARM ASSY-FR UPR	CA-H202
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007
				04.08~	L	ARM ASSY-LWR	CA-H007
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008
				04.08~	R	ARM ASSY-LWR	CA-H008
				00.06~	R	ARM ASSY-RR UPR	CA-H406
				98.03~		ARM ASSY-RR CTR	CA-H407
				98.03~		ARM ASSY-RR ASSIST	CA-H409
				98.03~		ARM ASSY-TRAILING	CA-H408
				00.06~	L	ARM ASSY-RR UPR	CA-H405
SONATA 02MY				98.03~	L	ARM ASSY-FR UPR	CA-H201
				98.03~	R	ARM ASSY-FR UPR	CA-H202
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007
				04.08~	L	ARM ASSY-LWR	CA-H007
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008
				04.08~	R	ARM ASSY-LWR.	CA-H008
				00.06~	L	ARM ASSY-RR UPR	CA-H405
				00.06~	R	ARM ASSY-RR UPR	CA-H406
				98.03~	CTR	ARM ASSY-RR CTR	CA-H407
				98.03~		ARM ASSY-RR ASSIST	CA-H409
				98.03~		ARM ASSY-TRAILING	CA-H408
SONATA 91MY				91.03~93.09	L	ARM & BALL JOINT ASSY-LWR	CA-H028
				88.06~93.09	R	ARM & BALL JOINT ASSY-LWR	CA-H029
SONATA 94MY				93.03~95.04	L	ARM COMPLETE-LWR	CA-H026
				93.03~95.04	R	ARM COMPLETE-LWR	CA-H027
				95.09~98.06	R	ARM COMPLETE-LWR	CA-H031

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.	
SONATA 99MY				93.03~98.06		ARM & BUSH ASSY-SUSP LWR	CA-H414	
				95.04~98.06	L	ARM & BALL JOINT ASSY-LWR	CA-H030	
				95.01~98.02	R	ARM & BALL JOINT ASSY-LWR	CA-H031	
				98.03~	R	ARM ASSY-RR UPR	CA-H406	
				98.03~	L	ARM ASSY-FR UPR	CA-H201	
				98.03~	R	ARM ASSY-FR UPR	CA-H202	
				98.03~00.08	L	ARM COMPLETE-FR LWR	CA-H009	
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007	
				98.03~00.08	R	ARM COMPLETE-FR LWR	CA-H010	
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008	
				98.03~	L	ARM ASSY-RR UPR	CA-H405	
				98.03~	CTR	ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
SONATA EF				98.03~06.08	L	ARM ASSY-FR UPR	CA-H201	
				98.03~06.08	R	ARM ASSY-FR UPR	CA-H202	
				98.03~00.08	L	ARM COMPLETE-FR LWR	CA-H009	
				02.09~06.01	L	ARM COMPLETE-FR LWR	CA-H007	
				04.08~	L	ARM ASSY-LWR	CA-H007	
				98.03~00.08	R	ARM COMPLETE-FR LWR	CA-H010	
				00.08~06.08	R	ARM COMPLETE-FR LWR	CA-H008	
				98.03~00.11	R	ARM ASSY-RR UPR	CA-H406	
				98.03~		ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
				98.03~00.11	L	ARM ASSY-RR UPR	CA-H405	
	SONATA(CHINA TAXI)				98.03~	L	ARM ASSY-FR UPR	CA-H201
				98.03~	R	ARM ASSY-FR UPR	CA-H202	
				00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007	
				04.08~	L	ARM ASSY-LWR	CA-H007	
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008	
				04.08~	R	ARM ASSY-LWR	CA-H008	
				00.06~	L	ARM ASSY-RR UPR	CA-H405	
				00.06~	R	ARM ASSY-RR UPR	CA-H406	
				98.03~		ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
SONATA(CHINA)					98.03~	L	ARM ASSY-FR UPR	CA-H201
					98.03~06.12	R	ARM ASSY-FR UPR	CA-H202
					00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007
				04.08~	L	ARM ASSY-LWR	CA-H007	
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008	
				04.08~	R	ARM ASSY-LWR	CA-H008	
				00.06~	L	ARM ASSY-RR UPR	CA-H405	
				00.06~	R	ARM ASSY-RR UPR	CA-H406	
				98.03~		ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
	SONATA(INDIA)				98.03~	L	ARM ASSY-FR UPR	CA-H201
					98.03~	R	ARM ASSY-FR UPR	CA-H202
					00.08~06.01	L	ARM COMPLETE-FR LWR	CA-H007
				04.08~	L	ARM ASSY-LWR	CA-H007	
				00.08~06.01	R	ARM COMPLETE-FR LWR	CA-H008	
				04.08~	R	ARM ASSY-LWR	CA-H008	
				00.06~	L	ARM ASSY-RR UPR	CA-H405	
				00.06~	R	ARM ASSY-RR UPR	CA-H406	
				98.03~	CTR	ARM ASSY-RR CTR	CA-H407	
				98.03~		ARM ASSY-RR ASSIST	CA-H409	
				98.03~		ARM ASSY-TRAILING	CA-H408	
STAREX		D4BB,D4BF,D4BH		DIESEL	96.11~02.01	L	ARM COMPLETE-UPR	CA-H211
		D4BB,D4BF,D4BH		DIESEL	96.11~02.01	R	ARM COMPLETE-UPR	CA-H212
		D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-UPR	CA-H209

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.	
STAREX 02MY	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-UPR	CA-H210	
	D4BB,D4BF,D4BH,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-LWR	CA-H032	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-LWR	CA-H033	
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	L	ARM COMPLETE-UPR	CA-H211	
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	R	ARM COMPLETE-UPR	CA-H212	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-UPR	CA-H209	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-UPR	CA-H210	
	D4BB,D4BF,D4BH,D4BH		DIESEL	96.11~07.12	L	ARM COMPLETE-LWR	CA-H032	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12	R	ARM COMPLETE-LWR	CA-H033	
STAREX 97MY	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	L	ARM COMPLETE-UPR	CA-H211	
	D4BB,D4BF,D4BH		DIESEL	96.11~02.01	R	ARM COMPLETE-UPR	CA-H212	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~05.01	L	ARM COMPLETE-UPR	CA-H209	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~05.01	R	ARM COMPLETE-UPR	CA-H210	
	D4BB,D4BF,D4BH,D4BH		DIESEL	96.11~05.01	L	ARM COMPLETE-LWR	CA-H032	
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~05.01	R	ARM COMPLETE-LWR	CA-H033	
TB(JAPAN)	G4AE,G4AE,,G4EC		GASOLINE	02.05~	L	ARM COMPLETE-LWR	CA-H046	
	G4AE,G4AE,,G4EC		GASOLINE	02.05~	R	ARM COMPLETE-LWR	CA-H047	
TIBURON	BETA		GASOLINE	96.04~96.07	L	ARM COMPLETE-LWR	CA-H034	
				95.03~01.10	L	ARM COMPLETE-LWR	CA-H034	
				96.04~96.07	R	ARM COMPLETE-LWR	CA-H035	
	BETA BETA,ALPHA BETA,ALPHA			GASOLINE	95.03~01.10	R	ARM COMPLETE-LWR	CA-H035
					95.03~01.10	L	COMPLETE-TRAILING ARM	CA-H415
					95.03~01.10	L	COMPLETE-TRAILING ARM	CA-H416
					95.03~01.10	R	COMPLETE-TRAILING ARM	CA-H416
VERNA				99.06~	L	ARM COMPLETE-LWR	CA-H036	
				99.06~	R	ARM COMPLETE-LWR	CA-H037	
				99.06~	L	ARM COMPLETE-TRAILING	CA-H410	
				99.06~	R	ARM COMPLETE-TRAILING	CA-H411	
				99.06~	RR/L	ARM ASSY-RR SUSPENSION	CA-H412	
				99.06~	ER/R	ARM ASSY-RR SUSPENSION	CA-H413	
				99.06~06.12	RR/L	ARM ASSY-RR SUSPENSION	CA-H422	
				99.06~06.12	RR/R	ARM ASSY-RR SUSPENSION	CA-H423	

KIA

AVELLA	B3,B5		GASOLINE	~99.11	L	ARM ASSY-LOW	CA-K019
				93.04~00.02	R	ARM ASSY-LOW	CA-K019
				93.04~93.05	L	ARM ASSY-LOW	CA-K019
BESTA				95.10~04.05	L/R	ARM UPPPER	CA-K204
				95.10~97.09	L/R	ARM ASSY-LWR	CA-K007
				96.09~04.05	L/R	ARM LWR	CA-K007
				04.01~08.06	L/R	LWR ARM ASSY-FR	CA-K007
				87.10~04.09	R	UPPER ARM ASSY	CA-K201
				87.10~04.09	L	UPPER ARM ASSY	CA-K202
				92.07~94.10	L	ARM ASSY-LWR	CA-K002
				92.07~01.10	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
BONGO FRONTIER 1T				92.07~	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
				87.10~04.09	R	UPPER ARM ASSY	CA-K201
				87.10~04.09	L	UPPER ARM ASSY	CA-K202
				92.07~94.10	R	ARM ASSY-LWR	CA-K001
				01.10~	L	ARM ASSY-LWR	CA-K002
BONGO(WIDE)				95.10~08.06	L/R	ARM ASSY-LWR	CA-K007
				94.10~00.07	R	ARM ASSY-LWR	CA-K001
				87.10~04.09	R	UPPER ARM ASSY	CA-K201
				V	L	UPPER ARM ASSY	CA-K202
				92.07~	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
				01.10~	L	ARM ASSY-LWR	CA-K002

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.								
BONG03				95.10-04.05	L/R	ARM UPPPER	CA-K204								
				95.10-08.06	L/R	ARM ASSY-LWR	CA-K007								
CAPITAL	FE,F8		GASOLINE	92.04-05.04	R	LINK ASSY-LATERAL	CA-K401								
				96.07-98.05	L	LINK ASSY-LATERAL	CA-K401								
	B5		GASOLINE	97.10-99.21	R	LINK ASSY-LATERAL	CA-K401								
	B5			97.10-99.12		LINK ASSY-TRAILING	CA-K404								
				92.04-05.04		LINK ASSY-TRAILING	CA-K404								
CARENS				99.01-04.03	R	ARM ASSY-LOW	CA-K017								
				98.02-04.03	L	ARM ASSY-LOW	CA-K018								
				99.01-99.06	R	ARM ASSY-LWR	CA-K003								
				99.01-99.06	L	ARM ASSY-LWR	CA-K004								
CARENS 00MY				99.01-04.03	R	ARM ASSY-LOW	CA-K017								
				98.02-04.03	L	ARM ASSY-LOW	CA-K018								
CARNIVAL				98.06-10.01	R	ARM ASSY-LWR	CA-K032								
				98.06-10.01	L	ARM ASSY-LWR	CA-K031								
CARSTAR				96.01-04.11	L	ARM COMPLETE-LWR	CA-K024								
				96.01-04.11	R	ARM COMPLETE-LWR	CA-K025								
CERATO				03.10-09.12	L	ARM COMPLETE-LWR	CA-K022								
				03.10-09.12	R	ARM COMPLETE-LWR	CA-K023								
CERATO 04MY				03.12-09.12	L	ARM COMPLETE-LWR	CA-K022								
				03.12-09.12	R	ARM COMPLETE-LWR	CA-K023								
CERATO 06MY				03.12-09.12	L	ARM COMPLETE-LWR	CA-K022								
				03.12-09.12	R	ARM COMPLETE-LWR	CA-K023								
CERATO SX				03.12-09.12	L	ARM COMPLETE-LWR	CA-K022								
				03.12-09.12	R	ARM COMPLETE-LWR	CA-K023								
CLARUS				95.10-00.10		LINK-TRAIL	CA-K405								
				~96.04	RR/R	LINK ASSY-LAT..RR	CA-K406								
				~96.04	RR/L	LINK ASSY-LAT..RR	CA-K407								
				95.10-00.10	FR/R	LINK ASSY-LAT..FRT	CA-K408								
				95.10-00.10	FR/L	LINK ASSY-LAT..FRT	CA-K409								
				96.04-00.10	R	LINK ASSY-LAT..RR	CA-K410								
				96.04-00.10	L	LINK ASSY-LAT..RR	CA-K411								
				95.10-00.10	R	ARM ASSY-LWR	CA-K020								
				95.10-00.10	L	ARM ASSY-LWR	CA-K021								
				CONCORD	FE,F8		GASOLINE	92.04-05.04	R	LINK ASSY-LATERAL	CA-K401				
								92.04-05.04	L	LINK ASSY-LATERAL	CA-K402				
FE,F8	GASOLINE	92.04-05.04			LINK ASSY-LAT NO.2		CA-K403								
		96.07-98.05	L		LINK ASSY-LATERAL		CA-K401								
B5	GASOLINE	97.10-99.12	R		LINK ASSY-LATERAL		CA-K401								
		96.07-98.05			LINK ASSY-LATERAL FR		CA-K402								
B5	GASOLINE	97.10-99.12	L		LINK ASSY-LATERAL		CA-K402								
		92.02-95.01			LINK ASSY-LAT NO.2		CA-K403								
B5	GASOLINE	97.10-99.12			LINK ASSY-TRAILING		CA-K404								
		FE,F8	GASOLINE		87.07-87.09			LINK ASSY-TRAILING	CA-K404						
92.04-05.04		LINK ASSY-TRAILING		CA-K404											
CREDOS				95.10-00.10		LINK-TRAIL	CA-K405								
				~96.04	RR/R	LINK ASSY-LAT.RR	CA-K406								
				~96.04	RR/L	LINK ASSY-LAT.RR	CA-K407								
				95.10-00.10	FR/R	LINK ASSY-LAT.FRT	CA-K408								
				95.10-00.10	FR/L	LINK ASSY-LAT.FRT	CA-K409								
				~00.04	R	ARM ASSY-LWR	CA-K020								
				~00.04	L	ARM ASSY-LWR	CA-K021								
				96.04-00.10	R	LINK ASSY-LAT.RR	CA-K410								
				96.04-00.10	L	LINK ASSY-LAT.RR	CA-K411								
				1.8 / 2.0				95.10-00.10	R	ARM ASSY-LWR	CA-K020				
								95.10-00.10	L	ARM ASSY-LWR	CA-K021				
								1.8				95.10-00.10		LINK-TRAIL	CA-K405
												95.10-00.10	FR/R	LINK ASSY-LAT.FRT	CA-K408
1.8				95.10-00.10	FR/L	LINK ASSY-LAT.FRT	CA-K409								
				96.04-00.10	R	LINK ASSY-LAT.RR	CA-K410								
				96.04-00.10	L	LINK ASSY-LAT.RR	CA-K411								
				95.10-00.10	R	ARM ASSY-LWR	CA-K020								

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
FESTIVA(CKD)		1.8		95.10~00.10	L	ARM ASSY-LWR	CA-K021
				90.02~01.12	L/R	LOW ARM	CA-K008
JOICE				96.01~03.03	L	ARM COMPLETE-LWR	CA-K024
				96.01~03.03	R	ARM COMPLETE-LWR	CA-K025
K2500				92.07~01.10	R	ARM ASSY-LWR	CA-K001
				97.04~04.09	R	UPPER ARM ASSY	CA-K201
				97.04~04.09	L	UPPER ARM ASSY	CA-K202
K2500 (1TON)				92.07~	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
K2500 04MY		2.2		01.10~	L	ARM ASSY-LWR	CA-K002
				01.10~	R	ARM ASSY-LWR	CA-K001
K2700		2.2		01.10~	L	ARM ASSY-LWR	CA-K002
				92.07~01.10	R	ARM ASSY-LWR	CA-K001
K2700 (1TON)				97.04~04.09	R	UPPER ARM ASSY	CA-K201
				97.04~04.09	L	UPPER ARM ASSY	CA-K202
				92.07~	R	ARM ASSY-LWR	CA-K001
K2700 04MY		2.2		92.07~01.10	L	ARM ASSY-LWR	CA-K002
				01.10~	L	ARM ASSY-LWR	CA-K002
K2700±		2.2		01.10~	R	ARM ASSY-LWR	CA-K001
				01.10~	L	ARM ASSY-LWR	CA-K002
K2700±(1TON)				92.07~01.10	R	ARM ASSY-LWR	CA-K001
				97.04~04.09	R	UPPER ARM ASSY	CA-K201
				97.04~04.09	L	UPPER ARM ASSY	CA-K202
K3000		2.2		92.07~	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
				01.10~	L	ARM ASSY-LWR	CA-K002
K3000 (1TON)				92.07~01.10	R	ARM ASSY-LWR	CA-K001
				97.04~04.09	R	UPPER ARM ASSY	CA-K201
				97.04~04.09	L	UPPER ARM ASSY	CA-K202
K3000±(1TON)		2.2		92.07~	R	ARM ASSY-LWR	CA-K001
				92.07~01.10	L	ARM ASSY-LWR	CA-K002
				01.10~	L	ARM ASSY-LWR	CA-K002
K3000S 04MY		2.2		01.10~	R	ARM ASSY-LWR	CA-K001
				01.10~	L	ARM ASSY-LWR	CA-K002
				01.10~	R	ARM ASSY-LWR	CA-K001
K4000S 04MY		2.2		01.10~	L	ARM ASSY-LWR	CA-K002
				01.10~	R	ARM ASSY-LWR	CA-K001
				01.10~	L	ARM ASSY-LWR	CA-K002
MAGENTIS 00MY				98.03~	L	ARM ASSY-FR UPR	CA-H201
				98.03~06.12	R	ARM ASSY-FR UPR	CA-H202
				00.08~06.01	L	ARM COMPLETE-LWR	CA-H007
				02.09~04.08	L	ARM COMPLETE-FR LWR	CA-H007
				04.08~	L	ARM ASSY-LWR	CA-H007
				00.08~06.01	R	ARM COMPLETE-LWR	CA-H008
				02.09~04.08	R	ARM COMPLETE-FR LWR	CA-H008
				04.08~	R	ARM ASSY-LWR.	CA-H008
				00.06~	L	ARM ASSY-RR UPR	CA-H405
				00.06~	R	ARM ASSY-RR UPR	CA-H406
				98.03~		ARM ASSY-RR CTR	CA-H407
				98.03~		ARM ASSY-RR ASSIST	CA-H409
				98.03~		ARM ASSY-TRAILING	CA-H408
MENTOR	B5,TE		GASOLINE	97.02~00.08	R	ARM ASSY-LOW	CA-K013
				99.04~00.05	R	ARM ASSY-LOW	CA-K013
				00.07~02.06	R	ARM ASSY-LOW	CA-K013
	B5		GASOLINE	97.02~99.06	L	ARM COMPT-LOW	CA-K014
				99.04~00.05	L	ARM ASSY-LOW	CA-K014
				99.09~00.08	L	ARM ASSY-LOW	CA-K014
	B5		GASOLINE	00.07~01.05	L	ARM ASSY-LOW	CA-K014
				98.02~04.03	R	ARM ASSY-LOW	CA-K017

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.				
MENTOR2	B5,TE		GASOLINE	98.02-04.03	L	ARM ASSY-LOW	CA-K018				
				97.02-99.06	R	ARM COMPT-LOW	CA-K013				
				99.04-00.05	R	ARM ASSY-LOW	CA-K013				
				99.09-00.08	R	ARM ASSY-LOW	CA-K013				
	B5		GASOLINE	00.07-02.06	R	ARM ASSY-LOW	CA-K013				
				97.02-99.06	L	ARM COMPT-LOW	CA-K014				
	B5,TE		GASOLINE	99.04-00.05	L	ARM ASSY-LOW	CA-K014				
				99.09-00.08	L	ARM ASSY-LOW	CA-K014				
	B5		GASOLINE	00.07-01.05	L	ARM ASSY-LOW	CA-K014				
				99.01-04.03	R	ARM ASSY-LOW	CA-K017				
				98.02-00.05	L	ARM COMP.-ASSY	CA-K018				
				99.01-04.03	L	ARM ASSY-LOW	CA-K018				
	OPIRUS 03MY					03.02-06.08	L	ARM ASSY-FR UPR	CA-H201		
						03.02-06.08	R	ARM ASSY-FR UPR	CA-H202		
03.02-06.08		L				ARM COMPLETE-FR LWR	CA-H007				
03.02-06.08		R				ARM COMPLETE-FR LWR	CA-H008				
03.02-06.08		L				ARM ASSY-FR UPR	CA-H201				
03.02-06.08		R				ARM ASSY-FR UPR	CA-H202				
03.02-06.08		L				ARM COMPLETE-FR LWR	CA-H007				
03.02-06.08		R				ARM COMPLETE-FR LWR	CA-H008				
OPTIMA								98.03-06.08	L	ARM ASSY-FR UPR	CA-H201
	98.03-06.12		R	ARM ASSY-FR UPR	CA-H202						
	98.03-99.11		L	ARM COMPLETE-LWR	CA-H009						
	99.11-00.08		L	ARM COMPLETE-FR LWR	CA-H009						
	02.09-06.08		L	ARM COMPLETE-FR LWR	CA-H007						
	98.03-99.11		R	ARM COMPLETE-LWR	CA-H010						
	~00.08		R	ARM COMPLETE-FR LWR	CA-H010						
	02.09-06.08		R	ARM COMPLETE-FR LWR	CA-H008						
	98.03~		L	ARM ASSY-RR UPR	CA-H405						
	98.03~		R	ARM ASSY-RR UPR	CA-H406						
	00.08-06.01		L	ARM COMPLETE-LWR	CA-H007						
	04.08~		L	ARM ASSY-LWR	CA-H007						
	00.08-06.01		R	ARM COMPLETE-LWR	CA-H008						
	04.08~		R	ARM ASSY-LWR.	CA-H008						
	98.03~			ARM ASSY-RR CTR	CA-H407						
	98.03~			ARM ASSY-RR ASSIST	CA-H409						
	98.03~			ARM ASSY-TRAILING	CA-H408						
	PARKTOWN							95.10-00.10		LINK-TRAIL	CA-K405
								95.10-00.10	R	LINK ASSY-LAT..FRT	CA-K408
								95.10-00.10	L	LINK ASSY-LAT..FRT	CA-K409
96.04-00.10		RR/R				LINK-LATERAL	CA-K410				
96.04-00.10		RR/L				LINK ASSY-LAT	CA-K411				
PREGIO				95.10-04.05	L/R	ARM UPPPER	CA-K204				
				95.10-08.06	L/R	ARM ASSY-LWR	CA-K007				
PREGIO 1996				95.10-04.05	L/R	ARM UPPPER	CA-K204				
				95.10-97.09	L/R	ARM ASSY-LWR	CA-K007				
				95.10-97.09	L/R	ARM ASSY-LWR	CA-K007				
PREGIO 2000~				95.10-08.06	L/R	ARM ASSY-LWR	CA-K007				
PRIDE		1.1		90.02-01.12	L/R	LOW ARM	CA-K008				
					L/R	LOW ARM	CA-K008				
PRIDE (EC/EGYPT)				90.02-01.12	L/R	LOW ARM	CA-K008				
PRIDE (IRAN) 1998				90.02-01.12	L/R	LOW ARM	CA-K008				
PRIDE (PHILL)				90.02-01.12	L/R	LOW ARM	CA-K008				
PRIDE (VIETNAM)				90.02-01.12	L/R	LOW ARM	CA-K008				
PRIDE 1999				90.02-01.12	L/R	LOW ARM	CA-K008				
REGAL				98.03-06.08	L	ARM ASSY-FR UPR	CA-H201				
				98.03-06.08	R	ARM ASSY-FR UPR	CA-H202				
				00.08-06.08	L	ARM COMPLETE-FR LWR	CA-H007				
				04.08~	L	ARM ASSY-LWR	CA-H007				
				00.08-06.08	R	ARM COMPLETE-FR LWR	CA-H008				
				04.08~	R	ARM ASSY-LWR	CA-H008				
				04.08~	L	ARM ASSY-LWR	CA-H008				
				98.03~	L	ARM ASSY-RR UPR	CA-H405				

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
				98.03~	R	ARM ASSY-RR UPR	CA-H406
				98.03~		ARM ASSY-RR CTR	CA-H407
				98.03~		ARM ASSY-RR ASSIST	CA-H409
				98.03~		ARM ASSY-TRAILING	CA-H408
RETONA				93.06~99.02	L/R	UPPER ARM ASSY	CA-K203
	RF-TCI,HW,FE		DIESEL	97.11~00.09	L/R	ARM ASSY-LWR	CA-K030
	FE,RF-TCI,HW		DIESEL	98.04~03.06	L/R	ARM ASSY-LWR	CA-K030
	RF-TCI,HW,FE		DIESEL	97.11~03.06	L/R	UPPER ARM ASSY	CA-K203
RIO	A3E,A5E,A5D		GASOLINE	99.11~02.09	R	ARM COMPLETE-LWR	CA-K029
	A3E,A5E,A5D		GASOLINE	99.11~02.09	L	ARM COMPLETE-LWR	CA-K028
	A3E,A5E,A5D		GASOLINE	02.06~05.06	L	ARM COMPLETE-LWR	CA-K026
	A3E,A5E,A5D		GASOLINE	02.06~05.06	R	ARM COMPLETE-LWR	CA-K027
RIO 00MY	A3E,A5E,A5D		GASOLINE	99.11~02.09	R	ARM COMPLETE-LWR	CA-K029
	A3E,A5E,A5D		GASOLINE	99.11~02.09	L	ARM COMPLETE-LWR	CA-K028
	A3E,A5E,A5D		GASOLINE	02.06~05.06	L	ARM COMPLETE-LWR	CA-K026
	A3E,A5E,A5D		GASOLINE	02.06~05.06	R	ARM COMPLETE-LWR	CA-K027
SEDONA 98MY				98.06~01.11	R	ARM ASSY-LWR	CA-K032
				98.06~10.01	L	ARM ASSY-LWR	CA-K031
SEPHIA	FE,F8		GASOLINE	92.04~05.04	R	LINK ASSY-LATERAL	CA-K401
	FE,F8		GASOLINE	92.04~05.04	L	LINK ASSY-LATERAL	CA-K402
	FE,F8		GASOLINE	92.04~05.04		LINK ASSY-LAT NO.2	CA-K403
				92.04~05.04		LINK ASSY-TRAILING	CA-K404
	B5		GASOLINE	97.10~99.12	R	LINK ASSY-LATERAL	CA-K401
	B5		GASOLINE	97.10~99.12	L	LINK ASSY-LATERAL	CA-K402
				92.02~95.01		LINK ASSY-LAT NO.2	CA-K403
				92.06~92.10	L	ARM ASSY-LOW	CA-K009
				97.06~97.10	R	ARM ASSY-LOW	CA-K009
				91.11~97.10	L	ARM ASSY-LOW	CA-K010
	B5		GASOLINE	92.06~99.12	L	ARM ASSY-LOW	CA-K010
	B5		GASOLINE	97.10~99.12		LINK ASSY-TRAILING	CA-K404
	FE,F8		GASOLINE	87.07~87.09		LINK ASSY-TRAILING	CA-K404
				96.07~98.05	L	LINK ASSY-LATERAL	CA-K401
				96.07~98.05		LINK ASSY-LATERAL FR	CA-K402
	B5		GASOLINE	97.10~99.12	R	ARM ASSY-LOW	CA-K009
				97.02~00.08	R	ARM ASSY-LOW	CA-K013
	B5,TE		GASOLINE	99.04~00.05	R	ARM ASSY-LOW	CA-K013
	B5		GASOLINE	00.07~02.06	R	ARM ASSY-LOW	CA-K013
				97.02~00.08	L	ARM ASSY-LOW	CA-K014
	B5,TE		GASOLINE	99.04~00.05	L	ARM ASSY-LOW	CA-K014
	B5		GASOLINE	00.07~01.05	L	ARM ASSY-LOW	CA-K014
				99.01~04.03	R	ARM ASSY-LOW	CA-K017
				98.02~04.03	L	ARM ASSY-LOW	CA-K018
SEPHIA2				97.02~00.08	R	ARM ASSY-LOW	CA-K013
	B5,TE		GASOLINE	99.04~00.05	R	ARM ASSY-LOW	CA-K013
	B5		GASOLINE	00.07~02.06	R	ARM ASSY-LOW	CA-K013
	B5,TE		GASOLINE	99.04~00.05	L	ARM ASSY-LOW	CA-K014
				99.09~00.07	L	ARM ASSY-LOW	CA-K014
	B5		GASOLINE	00.07~00.08	L	ARM ASSY-LOW	CA-K014
				99.01~04.03	R	ARM ASSY-LOW	CA-K017
				98.02~04.03	L	ARM ASSY-LOW	CA-K018
SHUMA				97.02~00.08	R	ARM ASSY-LOW	CA-K013
	B5,TE		GASOLINE	99.04~00.05	R	ARM ASSY-LOW	CA-K013
	B5		GASOLINE	00.07~02.06	R	ARM ASSY-LOW	CA-K013
				97.02~00.08	L	ARM ASSY-LOW	CA-K014
	B5,TE		GASOLINE	99.04~00.05	L	ARM ASSY-LOW	CA-K014
	B5		GASOLINE	00.07~01.05	L	ARM ASSY-LOW	CA-K014
				99.01~04.03	R	ARM ASSY-LOW	CA-K017
				98.02~04.03	L	ARM ASSY-LOW	CA-K018
SHUMA2				97.02~00.08	R	ARM ASSY-LOW	CA-K013
	B5,TE		GASOLINE	99.04~00.05	R	ARM ASSY-LOW	CA-K013
	B5		GASOLINE	00.07~02.06	R	ARM ASSY-LOW	CA-K013
				97.02~00.08	L	ARM ASSY-LOW	CA-K014

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.				
SPECTRA	B5,TE B5		GASOLINE	99.04-00.05	L	ARM ASSY-LOW	CA-K014				
				00.07-01.05	L	ARM ASSY-LOW	CA-K014				
				99.01-04.03	R	ARM ASSY-LOW	CA-K017				
				98.02-04.03	L	ARM ASSY-LOW	CA-K018				
	B5 B5 B5 FE,F8 B5,TE B5 B5,TE B5		GASOLINE	92.06-92.10	L	ARM ASSY-LOW	CA-K009				
				94.02-98.08	R	ARM ASSY-LOW	CA-K009				
				97.10-99.12	R	ARM ASSY-LOW	CA-K009				
				91.11-97.10	L	ARM ASSY-LOW	CA-K010				
				92.06-99.12	L	ARM ASSY-LOW	CA-K010				
				97.10-99.12		LINK ASSY-TRAILING	CA-K404				
				87.07-87.09		LINK ASSY-TRAILING	CA-K404				
				92.04-05.04		LINK ASSY-TRAILING	CA-K404				
				97.02-00.08	R	ARM ASSY-LOW	CA-K013				
				99.04-00.05	R	ARM ASSY-LOW	CA-K013				
				00.07-02.06	R	ARM ASSY-LOW	CA-K013				
				97.02-00.08	L	ARM ASSY-LOW	CA-K014				
99.04-00.05	L	ARM ASSY-LOW	CA-K014								
00.07-01.05	L	ARM ASSY-LOW	CA-K014								
99.01-04.03	R	ARM ASSY-LOW	CA-K017								
98.02-04.03	L	ARM ASSY-LOW	CA-K018								
SPECTRA WING	B5,TE B5 B5,TE B5		GASOLINE	97.02-00.08	R	ARM ASSY-LOW	CA-K013				
				99.04-00.05	R	ARM ASSY-LOW	CA-K013				
				00.07-02.06	R	ARM ASSY-LOW	CA-K013				
				97.02-00.08	L	ARM ASSY-LOW	CA-K014				
				99.04-00.05	L	ARM ASSY-LOW	CA-K014				
				00.07-01.05	L	ARM ASSY-LOW	CA-K014				
				99.01-04.03	R	ARM ASSY-LOW	CA-K017				
				98.02-04.03	L	ARM ASSY-LOW	CA-K018				
				SPORTAGE	RF-TCI,HW,FE FE,RF-TCI,HW RF-TCI,HW,FE		DIESEL	92.04-05.04	R	LINK ASSY-LATERAL	CA-K401
								92.04-05.04	L	LINK ASSY-LATERAL	CA-K402
93.06-99.02		UPPER ARM ASSY	CA-K203								
93.06-99.02	R	ARM ASSY-LWR	CA-K030								
97.11-00.09	L/R	ARM ASSY-LWR	CA-K030								
98.04-03.06	L/R	ARM ASSY-LWR	CA-K030								
96.07-98.05	L	LINK ASSY-LATERAL	CA-K401								
96.07-98.05	L	LINK ASSY-LATERAL	CA-K402								
97.11-03.06	L/R	UPPER ARM ASSY	CA-K203								
TITAN(JUMBO)								92.07~	R	ARM ASSY-LWR	CA-K001
								92.07~	L	ARM ASSY-LWR	CA-K002
VISTO								97.08-07.01	L	ARM COMPLETE-LWR	CA-H003
				97.08-07.01	R	ARM COMPLETE-LWR	CA-H004				

DAEWOO

CIELO					L	ARM A-CONT	CA-D003
					R	ARM A-CONT	CA-D004
						ARM A-CONT	CA-D003
						ARM A-CONT	CA-D004
DAMAS/LABO						ROD ASSY-STEERING DRAG	CL-D401
						ARM A-FRT SPNSN CONTROL	CA-D202
						ARM-STEERING INTERMEDIATE	CA-D601
						ROD ASSY-STEERING DRAG	CL-D402
						ROD ASSY-STEERING DRAG	CL-D403
ESPERO					L	ARM A-CONT	CA-D003
					R	ARM A-CONT	CA-D004
						ARM A-CONT	CA-D003
						ARM A-CONT	CA-D004
GENTRA(T250)					L	ARM A-CONT	CA-D017

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
KALOS(T200)					R	ARM A-CONT	CA-D018
					L	ARM A-CONT	CA-D017
					R	ARM A-CONT	CA-D018
LACETTI(J200)	FAM1,FAM2				R	ARM A-CONT	CA-D002
						ARM A-CONT	CA-D001
					L	ARM A-CONT	CA-D001
LANOS(T100)						ARM A-CONT	CA-D002
					L	ARM A-CONT	CA-D003
						ARM A-CONT	CA-D003
LEGANZA(V100)	FAM1,FAM2 FAM1,FAM2 FAM1,FAM2 FAM1,FAM2					ARM A-CONT	CA-D004
					R	ARM A-CONT	CA-D004
					L	ARM A-CONT	CA-H902
LEMAN					L	ARM A-CONT	CA-H902
						ARM A-CONT	CA-H903
					R	ARM A-CONT	CA-H903
MAGNUS(V200)	FAM2,XK FAM2,XK FAM2,XK				L	ARM A-CONT	CA-D003
						ARM A-CONT	CA-D004
					R	ARM A-CONT	CA-D003
MATIZ(M100)						ARM A-CONT	CA-D004
					L	ARM A-CONT	CA-D009
					R	ARM A-CONT	CA-D009
NUBIRA(J100)					L	ARM A-CONT	CA-D010
						ARM A-CONT	CA-D010
					R	ARM A-CONT	CA-D010
MATIZ(M100)					L	ARM A-CONT	CA-D023
						ARM A-CONT	CA-D024
					R	ARM A-CONT	CA-D024
MATIZ(M100)						ARM A-CONT	CA-D007
					L/R	ARM A-CONT	CA-D008
						ARM A-CONT	CA-D008
MATIZ(M100)					L/R	ARM A-FRT SPNSN CONTROL	CA-D201
						ARM A-TRAILING	CA-D402
						ARM A-FRT SPNSN CONTROL	CA-D201
NUBIRA(J100)						LINK A-TRAILING	CA-D407
					RR/L	LINK A-TRAILING	CA-D407
					RR	LINK A-TRAILING	CA-D407
					RR/R	LINK A-TRAILING	CA-D408
					RR	LINK A-TRAILING	CA-D408
					FR	LINK A-PARALLEL	CA-D408
					RR	LINK A-PARALLEL	CA-D404
					L	ARM A-CONT	CA-D405
					R	ARM A-CONT	CA-D019
					RR	LINK A-TRAILING	CA-D020
NUBIRA2(J150)					L	ARM A-CONT	CA-D406
					R	ARM A-CONT	CA-D013
PRINCE						ARM A-CONT	CA-D014
						ARM A-CONT	CA-D021
					L	ARM A-CONT	CA-D022
REZZO(U100)					R	ARM A-CONT	CA-D021
						ARM A-CONT	CA-D022
					L	ARM A-CONT	CA-D022
TICO					L	ARM A-CONT	CA-D015
						ARM A-CONT	CA-D015
					R	ARM A-CONT	CA-D016
TICO						ARM ASSY- TRAILING	CA-D402
						ARM A-FRT SPNSN CONTROL	CA-D201

SSANGYONG

MUSSO				94.03~00.09 00.09~05.04 94.03~95.11 94.03~95.11		ARM & BUSH ASSY-RR UPR	CA-S001
						ARM & BUSH ASSY-RR UPR	CA-S001
						ARM & BUSH ASSY-RR LWR	CA-S002
						ARM & BUSH ASSY-RR LWR	CA-S003
NEW KORANDO				94.03~00.09 00.09~05.09		ARM & BUSH ASSY-RR UPR	CA-S001
						ARM & BUSH ASSY-RR UPR	CA-S001

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
HYUNDAI							
ACCENT 00MY				99.06~		BALL JOINT ASSY- LWR ARM	CJ-H010
ACCENT 06MY				09.10~		BALL JOINT ASSY	CJ-H015
ACCENT 06MY(CHINA)				05.02~		BALL JOINT ASSY	CJ-H015
ACCENT 95MY	BETA		GASOLINE	98.11~01.10		BALL JOINT ASSY- LWR ARM	CJ-H010
ACCENT(INDIA)				99.06~		BALL JOINT ASSY- LWR ARM	CJ-H010
ATOS				97.08~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
ATOS 01MY				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
ATOS PRIME 01MY				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
ATOS PRIME 06MY				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
ATOS PRIME 99MY				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
ATOZ 98MY				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
AVANTE 06MY				05.09~		BALL JOINT ASSY	CJ-K601
				06.05~09.06		BALL JOINT ASSY	CJ-H602
AVANTE HD				06.05~09.06		BALL JOINT ASSY	CJ-H602
CENTENNIAL				00.01~09.07		BALL JOINT KIT-RR SUSP CTR	CJ-H002
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
CLICK				99.06~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
COUPE 01MY						BALL JOINT KIT- RR SUSP CTR	CJ-H003
COUPE 01MY(JAPAN)						BALL JOINT KIT- RR SUSP CTR	CJ-H003
COUPE 07MY	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
COUPE 07MY(JAPAN)	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
COUPE 97MY	BETA		GASOLINE	98.11~01.10		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
ECUUS				00.01~09.07		BALL JOINT KIT-RR SUSP CTR	CJ-H002
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
ELANTRA				90.11~95.11		BALL JOINT ASSY-FR LWR ARM	CJ-H004
				94.11~		BALL JOINT ASSY-LWR ARM	CJ-H004
				90.12~95.09		BALL JOINT KIT-SUSP LWR ARM	CJ-H004
ELANTRA 00MY						BALL JOINT KIT- RR SUSP CTR	CJ-H003
	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
ELANTRA 06MY				05.09~		BALL JOINT ASSY	CJ-K601
				06.05~09.06		BALL JOINT ASSY	CJ-H602
ELANTRA 91MY				90.12~95.09		BALL JOINT KIT-SUSP LWR ARM	CJ-H004
ELANTRA 96MY	BETA		GASOLINE	98.11~01.10		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
ELANTRA(CHINA TAXI)	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
ELANTRA(CHINA)	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
ELANTRA(INDIA)	BETA		GASOLINE			BALL JOINT ASSY-FR LWR ARM	CJ-H010
ELANTRA(JAPAN)						BALL JOINT KIT-SUSP UPR ARM	CJ-H003
	BETA		GASOLINE			BALL JOINT ASSY- LWR ARM	CJ-H010
EXCEL				88.07~95.03		BALL JOINT ASSY -LWR ARM	CJ-H005
GALLOPER				87.01~03.12	L	BALL-JOINT UPR	CJ-H202
				87.01~03.12	R	BALL-JOINT UPR	CJ-H202
				91.10~03.12		BALL JOINT-LWR	CJ-H011
GALLOPER2				87.01~03.12	L	BALL-JOINT UPR	CJ-H202
				87.01~03.12	R	BALL-JOINT UPR	CJ-H202
				92.10~03.12		BALL JOINT-LWR	CJ-H011
GETZ				99.06~		BALL JOINT ASSY- LWR ARM	CJ-H010
GETZ05MY(INDIA)				99.06~		BALL JOINT ASSY- LWR ARM	CJ-H010
GETZ07MY(INDIA)				99.06~		BALL JOINT ASSY- LWR ARM	CJ-H010
GRACE	D4BA,D4BF,L4CS		DIESEL	86.03~99.07	L/R	BALL JOINT-ARM UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12	L	BALL JOINT-ARM UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12		BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
	D4BH,D4BH		DIESEL	02.11~	L	BALL JOINT-ARM UPR	CJ-H201
	D4BH,D4BH		DIESEL	96.11~07.05		BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~06.12	L	BALL JOINT-ARM UPR	CJ-H201
				96.03~06.12		BALL JOINT KIT SUSP UPR ARM	CJ-H201

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
	D4BA,D4BF,L4CS		DIESEL	86.03~03.12	R	BALL JOINT-ARM UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	86.03~03.12		BALL JOINT-LWR	CJ-H006
	D4BA,D4BF,L4CS		DIESEL			BALL JOINT ASSY-LWR ARM	CJ-H006
				87.01~03.12		BALL JOINT-LWR	CJ-H006
						BALL JOINT ASSY-LWR ARM	CJ-H006
GRANDEUR				98.03~	FR	BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
				93.03~98.03		BALL JOINT KIT-FRT.LWR ARM	CJ-H007
				92.09~05.01		BALL JOINT KIT-SUSP LWR ARM	CJ-H007
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
				92.09~05.01		BALL JOINT ASSY-LWR ARM	CJ-H007
GRANDEURQ20				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
GRANDEURXG				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
GRANDEUR XG (JAPAN)				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
GRANDEUR XG25				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
GRANDEUR XG250				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
GRANDEUR XG30				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
GRANDEUR XG300				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
H-1 02MY	D4BB,D4BF,L4CS,D4BH		DIESEL	02.10~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
	D4BH,D4BH		DIESEL	96.11~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
	D4BH,D4BH		DIESEL	02.11~	L	BALL JOINT-ARM UPR	CJ-H201
	D4BH,D4BH		DIESEL	96.11~07.05		BALL JOINT-ARM UPR	CJ-H201
H-1 04MY	D4BB,D4BF,L4CS,D4BH		DIESEL	02.10~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
	D4BH,D4BH		DIESEL	00.07~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
				96.11~07.05		BALL JOINT-ARM UPR	CJ-H201
H-1 98MY	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
	D4BH,D4BH		DIESEL	96.11~07.05		BALL JOINT-ARM UPR	CJ-H201
H-100	D4BA,D4BF,L4CS		DIESEL	~04.03		BALL JOINT ASSY-LWR ARM	CJ-H006
H-100 04MY	D4BH,D4BH		DIESEL	02.11~	L	BALL JOINT-ARM UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	03.01~		BALL JOINT ASSY-LWR ARM	CJ-H006
H-100 (TRUCK)				93~97	L	BALL JOINT-LWR	CJ-H008
				93~97	R	BALL JOINT-LWR	CJ-H008
	D4BA,D4BF,L4CS		DIESEL	~04.03		BALL JOINT-LWR	CJ-H006
H-100 (AU TRUCK)	D4BA,D4BF,L4CS		DIESEL	03.01~		BALL JOINT ASSY-LWR ARM	CJ-H006
				96.03~06.12		BALL JOINT KIT SUSP UPR ARM	CJ-H201
H-100(MINI BUS)	D4BA,D4BF,L4CS		DIESEL	93.07~03.12	L	BALL JOINT-ARM UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12		BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12		BALL JOINT-ARM UPR RH	CJ-H201
I20(INDIA)				99.06~	FR	BALL JOINT ASSY- LWR ARM	CJ-H010
i30				05.09~		BALL JOINT ASSY	CJ-K601
i30 (JAPAN)				05.09~		BALL JOINT ASSY	CJ-K601
i30 CW				05.09~		BALL JOINT ASSY	CJ-K601
i30 CW(JAPAN)				05.09~		BALL JOINT ASSY	CJ-K601

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
GALLOPER INNOVATION				87.01~03.12	L	BALL-JOINT UPR	CJ-H202
				87.01~03.12	R	BALL-JOINT UPR	CJ-H202
				92.10~03.12		BALL JOINT-LWR	CJ-H011
LAVITA 08MY	BETA		GASOLINE		FR	BALL JOINT ASSY-FR LWR ARM	CJ-H010
LAVITA 09MY	BETA		GASOLINE		FR	BALL JOINT ASSY-FR LWR ARM	CJ-H010
MARCIA				93.03~98.06		BALL JOINT KIT-RR SUSP ARM	CJ-H401
MATRIX					RR	BALL JOINT KIT- RR SUSP CTR	CJ-H003
MATRIX08MY	BETA		GASOLINE		FR	BALL JOINT ASSY-FR LWR ARM	CJ-H010
MATRIX09MY	BETA		GASOLINE		FR	BALL JOINT ASSY-FR LWR ARM	CJ-H010
MATRIX2006	BETA		GASOLINE		FR	BALL JOINT ASSY-FR LWR ARM	CJ-H010
MX ATOS		1.1		97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001
PORTER	D4BA,D4BF,L4CS		DIESEL	86.03~99.07	L/R	BALL-JOINT UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12	L	BALL-JOINT UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	93.07~03.12	L	BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
				87.01~03.12	L	BALL-JOINT UPR	CJ-H202
	D4BH,D4BH		DIESEL	02.11~	L	BALL-JOINT UPR	CJ-H201
	D4BH,D4BH		DIESEL	96.11~07.05		BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~06.12	L	BALL-JOINT UPR	CJ-H201
				96.03~06.12		BALL JOINT KIT SUSP UPR ARM	CJ-H201
				87.01~03.12	R	BALL-JOINT UPR	CJ-H202
	D4BA,D4BF,L4CS		DIESEL	86.03~03.12	R	BALL-JOINT UPR	CJ-H201
	D4BA,D4BF,L4CS		DIESEL	86.03~04.03		BALL JOINT-LWR	CJ-H006
				87.01~96.02	L	BALL JOINT-LWR	CJ-H008
				87.01~96.02	R	BALL JOINT-LWR	CJ-H008
						BALL JOINT-LWR	CJ-H006
SANTA FE				00.01~09.07		BALL JOINT KIT-RR SUSP CTR	CJ-H002
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
SANTA FE(JAPAN)				00.01~09.07		BALL JOINT KIT-RR SUSP CTR	CJ-H002
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
SANTA FE06MY				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
SANTA FE10MY				00.01~		BALL JOINT ASSY-LWR ARM	CJ-H002
SANTAMO				98.03~02.12		BALL JOINT ASSY-LWR ARM	CJ-K005
SCOUPE				88.07~95.03		BALL JOINT ASSY-FR LWR ARM	CJ-H005
SONATA				93.03~98.06		BALL JOINT KIT-RR SUSP ARM	CJ-H401
				93.04~98.06		BALL JOINT ASSY-RR LWR ARM	CJ-H401
SONATA (INDIA)				98.03~	FR	BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
					FR	BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~	FR	BALL JOINT KIT-RR SUSP CTR	CJ-H003
				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
SONATA 02MY				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
				98.09~		BALL JOINT ASSY	CJ-H601
			98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601	
SONATA 91MY				86.12~93.08		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
SONATA 94MY				93.03~98.03		BALL JOINT KIT-FRT.LWR ARM	CJ-H007
				92.09~05.01		BALL JOINT KIT-SUSP LWR ARM	CJ-H007
				93.03~98.06		BALL JOINT KIT-RR SUSP ARM	CJ-H401
SONATA 99MY				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
SONATA EF				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
						BALL JOINT KIT- RR SUSP CTR	CJ-H003
SONATA(CHINA TAXI)				00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
	BETA		GASOLINE	98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003
SONATA(CHINA)				98.09~		BALL JOINT ASSY-FR LWR ARM	CJ-H010
				98.03~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-SUSP UPR ARM FR	CJ-H003

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
STAREX	BETA		GASOLINE	00.01~		BALL JOINT KIT-RR SUSP CTR	CJ-H003
				98.09~		BALL JOINT ASSY-FR LWR ARM	CJ-H010
						BALL JOINT ASSY	CJ-H601
STAREX 02MY	D4BB,D4BF,L4CS,D4BH D4BB,D4BF,L4CS,D4BH		DIESEL	02.10~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
				00.07~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
				96.11~07.12		BALL JOINT KIT-SUSP LWR ARM	CJ-H009
STAREX 97MY	D4BB,D4BF,L4CS,D4BH D4BB,D4BF,L4CS,D4BH D4BH,D4BH D4BH,D4BH		DIESEL	02.10~07.12	L	BALL JOINT ASSY-LWR ARM	CJ-H009
				00.07~07.12		BALL JOINT ASSY-LWR ARM	CJ-H009
				96.11~07.12		BALL JOINT KIT-SUSP LWR ARM	CJ-H009
				02.11~		BALL JOINT-UPR ARM LH	CJ-H201
				96.11~07.05		BALL JOINT KIT-FR SUSP UPR ARM	CJ-H201
TB(JAPAN)				99.06~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
TERRACAN	D4BH D4BH		DIESEL	01.01~06.10		BALL JOINT ASSY-UPR	CJ-H013
				01.01~06.10		BALL JOINT ASSY-LWR	CJ-H012
TERRACAN(INDIA)	D4BH		DIESEL	01.01~06.10		BALL JOINT ASSY-LWR	CJ-H012
TIBURON	BETA		GASOLINE	98.11~01.10		BALL JOINT ASSY- LWR ARM	CJ-H010
				86.12~		BALL JOINT ASSY- LWR ARM	CJ-H010
						BALL JOINT ASSY-FR LWR ARM	CJ-H010
TRAJET				00.12~07.06		BALL JOINT ASSY-LWR ARM	CJ-H016
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
TRAJET XG				00.01~09.07		BALL JOINT KIT-RR SUSP CTR	CJ-H002
				00.12~07.06		BALL JOINT ASSY-LWR ARM	CJ-H016
				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
TRAJET(JAPAN)				99.03~		BALL JOINT ASSY-LWR ARM	CJ-H002
TUCSON				04.03~		BALL JOINT ASSY	CJ-H014
TUCSON(CHINA)				04.03~		BALL JOINT ASSY	CJ-H014
TUCSON(INDIA)				04.03~		BALL JOINT ASSY	CJ-H014
TUCSON(JAPAN)				04.03~		BALL JOINT ASSY	CJ-H014
TUSCANI	BETA		GASOLINE	98.11~01.10		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				86.12~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
				04.07~		JOINT-BALL	CJ-H010
						BALL JOINT ASSY-FR LWR ARM	CJ-H010
VERNA	BETA		GASOLINE	98.11~01.10		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				86.12~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
				04.07~		JOINT-BALL	CJ-H010
						BALL JOINT ASSY-FR LWR ARM	CJ-H010
VERNA (BL-NEW)				05.02~		BALL JOINT ASSY	CJ-H015
VERNA (HYBRID)				05.02~		BALL JOINT ASSY	CJ-H015
VERNA 06MY				05.02~		BALL JOINT ASSY	CJ-H015
VERNA 06MY(INDIA)				05.02~		BALL JOINT ASSY	CJ-H015

KIA

BESTA		2.2 2.2		92.07~00.12		JOINT-BALL(10MM)	CZ-K080
				92.07~00.07		END ASSY-CONTROL ROD(10MM)	CZ-K081
				92.07~		BALL JOINT(LOW)	CJ-K001
				92.07~		BALL JOINT (UP)	CJ-K201
				99.07~99.12		JOINT - BALL SHIFT ROD(10mm)	CZ-K080
				90.10~98.03		BALL JOINT(10mm)	CZ-K080
				99.07~99.12		JOINT - BALL SHIFT ROD(10mm)	CZ-K081
				~94.07		BALL JOINT(10mm)	CZ-K081
				95.10~05.10		BALL JOINT LWR ARM	CJ-K002
				94.10~00.07		BALL JOINT-LOW	CJ-K001
				90.10~98.03		JOINT.BALL SHIFT ROD	CZ-K080

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
BONGO FRONTIER 1T				91.01~93.03		JOINT.BALL SHIFT ROD	CZ-K081
				97.11~05.11		BUSH-UP.ARM	CB-K205
BONGO(WIDE)				92.07~		BALL JOINT(LOW)	CJ-K001
				94.10~00.07		BALL JOINT (UP)	CJ-K201
BONG03				94.10~00.07		BALL JOINT-LOW	CJ-K001
				97.11~05.04		BALL JOINT(LOW)	CJ-K001
CARENS				95.10~05.10		BALL JOINT-LOW	CJ-K001
				97.11~05.04		BUSH-UP.ARM	CB-K205
CARENS 00MY				95.10~05.10		BALL JOINT LWR ARM	CJ-K002
				05.09~		BALL JOINT ASSY	CJ-K601
CARENS 06MY				97.02~07.12		BALL JOINT-LOW	CJ-K004
				97.02~		BALL JOINT-LOW	CJ-K004
CARNIVAL				05.09~		BALL JOINT ASSY	CJ-K601
CARNIVAL 98MY				97.11~05.11		BUSH-UP.ARM	CB-K205
CARSTAR				97.11~05.11		BUSH-UP.ARM	CB-K205
CERATO	BETA		GASOLINE	98.03~02.12		BALL JOINT ASSY-LWR ARM	CJ-K005
CERATO 04MY	BETA		GASOLINE	98.11~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				86.12~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
				04.07~		JOINT-BALL	CJ-H010
CERATO 06MY	BETA		GASOLINE	04.07~		BALL JOINT ASSY-FR LWR ARM	CJ-H010
				04.07~		JOINT-BALL	CJ-H010
CERATO 08MY				04.07~		BALL JOINT ASSY-FR LWR ARM	CJ-H010
CERATO KOUP 08MY				05.09~		JOINT-BALL	CJ-H010
CERATO SX	BETA		GASOLINE	05.09~		BALL JOINT ASSY	CJ-K601
CERES	SC		DIESEL	98.11~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				86.12~		BALL JOINT KIT-SUSP LWR ARM	CJ-H010
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
				04.07~		JOINT-BALL	CJ-H010
CLARUS	FE,F8		GASOLINE	04.07~		BALL JOINT ASSY-FR LWR ARM	CJ-H010
				92.07~00.12		JOINT-BALL(10MM)	CZ-K080
CONCORD	FE,F8		GASOLINE	92.07~00.12		JOINT - BALL	CJ-K006
CREDOS2	FE,F8		GASOLINE	95.10~00.10		JOINT - BALL	CJ-K006
				92.04~04.11		JOINT-BALL	CJ-K006
FORTE 08MY				95.10~00.10		JOINT - BALL	CJ-K006
				92.04~04.11		JOINT-BALL	CJ-K006
JOICE				95.10~00.10		JOINT - BALL	CJ-K006
K2500 (1TON)				92.04~04.11		JOINT - BALL	CJ-K006
K2500 04MY				92.07~		BALL JOINT ASSY	CJ-K601
				92.07~		BALL JOINT (UP)	CJ-K201
K2700 (1TON)				92.07~		BALL JOINT(LOW)	CJ-K001
				92.07~		BALL JOINT (UP)	CJ-K201
K2700 04MY				92.07~		BALL JOINT(LOW)	CJ-K001
				92.07~		BALL JOINT (UP)	CJ-K201
K2700±(1TON)				92.07~		BALL JOINT(LOW)	CJ-K001
				92.07~		BALL JOINT (UP)	CJ-K201
K3000 (1TON)				92.07~		BALL JOINT (UP)	CJ-K201
				92.07~		BALL JOINT(LOW)	CJ-K001
K3000±(1TON)				92.07~		BALL JOINT (UP)	CJ-K201
				92.07~		BALL JOINT(LOW)	CJ-K001
K3000S 04MY				92.07~		BALL JOINT (UP)	CJ-K201
				92.07~		BALL JOINT(LOW)	CJ-K001
				92.07~		BALL JOINT (UP)	CJ-K201
				92.07~		BALL JOINT(LOW)	CJ-K001
LOTZE				92.07~		BALL JOINT(LOW)	CJ-K001
MAGENTIS 00MY				05.09~		BALL JOINT ASSY	CJ-K601
MAGENTIS 06MY				98.09~		BALL JOINT ASSY	CJ-H601
				05.09~		BALL JOINT ASSY	CJ-K601

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
MAGENTIS 09MY				05.09~		BALL JOINT ASSY	CJ-K601
MENTOR	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
MENTOR2	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
MORNING				04.01~		BALL JOINT ASSY-LWR ARM	CJ-K012
OPTIMA				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
OPTIMA 00MY				98.09~		BALL JOINT ASSY	CJ-H601
OPTIMA 06MY				05.09~		BALL JOINT ASSY	CJ-K601
OPTIMA 09MY				05.09~		BALL JOINT ASSY	CJ-K601
PICANTO 04MY				04.01~		BALL JOINT ASSY-LWR ARM	CJ-K012
PICANTO 08MY				04.01~		BALL JOINT ASSY-LWR ARM	CJ-K012
				99.06~		BALL JOINT ASSY-LWR ARM	CJ-H010
POTENTIA				98.06~05.04		JOINT-BALL.IN.	CT-K501
POTENTIA (NEW)		2.5		98.06~05.04		JOINT-BALL.IN.	CT-K501
PREGIO				97.11~05.11		BUSH-UP.ARM	CB-K205
				95.10~05.10		BALL JOINT LWR ARM	CJ-K002
PRIDE (JB)				05.02~		BALL JOINT ASSY	CJ-H015
PRIDE HYBRID				05.02~		BALL JOINT ASSY	CJ-H015
REGAL				98.09~		BALL JOINT ASSY	CJ-H601
				98.03~		BALL JOINT KIT-FR SUSP LWR ARM	CJ-H601
RETONA						BALL JOINT LWR	CJ-K007
				99.12~05.04		BUSH-UP.ARM	CB-K205
	RF-TCI,HW,FE		DIESEL	94.11~03.06		BALL JOINT LWR	CJ-K007
	RF-TCI,HW,FE		DIESEL	97.11~05.11		BUSH-UP.ARM	CB-K205
RIO 05MY				05.02~		BALL JOINT ASSY	CJ-H015
SEDONA 98MY				97.11~05.11		BUSH-UP.ARM	CB-K205
SEPHIA				92.06~92.10		JOINT-BALL.LOW	CJ-K003
				93.06~96.02		JOINT-BALL UP	CJ-K003
				95.09~98.08		JOINT-BALL	CJ-K003
	B5		GASOLINE	98.06~99.12		JOINT-BALL	CJ-K003
	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SEPHIA2				~07.12		BALL JOINT-LOW	CJ-K004
SEPHIA2	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SHUMA				~07.12		BALL JOINT-LOW	CJ-K004
	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SHUMA KOUP 08MY				05.09~		BALL JOINT ASSY	CJ-K601
SHUMA2	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SPECTRA				~07.12		BALL JOINT-LOW	CJ-K004
	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SPECTRAWING				~07.12		BALL JOINT-LOW	CJ-K004
	B5,TE		GASOLINE	97.02~		BALL JOINT-LOW	CJ-K004
SPORTAGE				99.12~05.04		BUSH-UP.ARM	CB-K205
	RF-TCI,HW,FE		DIESEL	94.11~03.06		BALL JOINT LWR	CJ-K007
	RF-TCI,HW,FE		DIESEL	97.11~05.11		BUSH-UP.ARM	CB-K205
SPORTAGE (NEW)				04.03~		BALL JOINT ASSY	CJ-H014
TOPIC				92.07~00.12		JOINT-BALL(10MM)	CZ-K080
				92.07~00.07		END ASSY-CONTROL ROD(10MM)	CZ-K081
				99.07~99.12		JOINT - BALL SHIFT ROD(10mm)	CZ-K080
				91.10~98.03		BALL JOINT(10mm)	CZ-K080
				97.07~99.12		JOINT - BALL SHIFT ROD(10mm)	CZ-K081
				~94.07		BALL JOINT(10mm)	CZ-K081
				91.01~93.03		JOINT.BALL SHIFT ROD	CZ-K080
				91.01~93.03		JOINT.BALL SHIFT ROD	CZ-K081
VISTO				97.08~99.12		BALL JOINT ASSY-FR LWR ARM	CJ-H001
				97.12~07.01		BALL JOINT ASSY-LWR ARM	CJ-H001

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
GM DAEWOO							
KALOS(T200)						JOINT SET-BALL ,CONT ARM	CJ-D005
LANOS(T100)						BALL JOINT SET-CONT ARM	CJ-D001
LANOS(T100)						JOINT A-BALL,CONTROL ARM	CJ-D001
LEGANZA(V100)						BALL JOINT SET-CONT ARM	CJ-K010
LEMAN						BALL JOINT SET-CONT ARM	CJ-D001
						JOINT A-BALL,CONTROL ARM	CJ-D001
CIELO						BALL JOINT SET-CONT ARM	CJ-D001
						JOINT A-BALL,CONTROL ARM	CJ-D001
NUBIRA(J100)						BALL JOINT SET-CONT ARM/NBR1,2	CJ-D003
PRINCE						JOINT-CONTROL ARM BALL	CJ-D002

SSANGYONG

ISTANA	OM661,OM662		DIESEL		L	B/JOINT ASSY-UPR	CJ-S002
					R	B/JOINT ASSY-LWR ARM	CJ-S003
						B/JOINT ASSY-LWR ARM	CJ-S004
MUSSO	OM661,OM662,E32		DIESEL	94.06-05.04	L	END ASSY-FRT SUSPENSION	CJ-S001
				94.04-05.04	L	END ASSY-FRT SUSPENSION	CJ-S001
NEW KORANDO	OM661,OM662,E32		DIESEL	94.06-05.04	L	END ASSY-FRT SUSPENSION	CJ-S001
				94.04-05.04	L	END ASSY-FRT SUSPENSION	CJ-S001

SAMSUNG

SV110(YAMOUZINE)	TD27		DIESEL			BJT ASSY-FRONT SUSPENSION,UPPER	CJ-U001
------------------	------	--	--------	--	--	---------------------------------	---------

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
-------	--------	---------	------	-------------	----------	-----------	-------------

BUSHING - SUSPENSION ARM

HYUNDAI

ACCENT				94.04~07.01		BUSH-LWR ARM RR	CB-H001
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				94.04~07.08	L	BUSH-ROD	CB-H002
				94.04~07.08	R	BUSH-ROD	CB-H003
				94.04~99.10		BUSH-TRAILING ARM	CB-H201
				94.04~		BUSH-RR SUSPENSION ARM	CB-H401
ACCENT 00MY	G4AE,G4AE,,G4EC		GASOLINE	99.06~		BUSH-RR SUSP RR ARM	CB-H215
				02.05~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM(G)	CB-H052
				99.06~		BUSH-TRAILING ARM	CB-H214
				99.06~		BUSH-TRAILING ARM	CB-H213
				99.06~		BUSH-RR SUSPENSION ARM	CB-H212
ACCENT 06MY				05.02~		BUSH-FR LWR ARMA	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
ACCENT 06MY(INDIA)				05.02~		BUSH-FR LWR ARMA	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
ACCENT 95MY				94.04~99.12		BUSH-LWR ARM	CB-H001
				98.10~07.08		BUSH-LWR ARM RR	CB-H001
				94.04~07.08	L	BUSH-ROD	CB-H002
				94.04~07.08	R	BUSH-ROD	CB-H003
				94.04~99.10		BUSH-TRAILING ARM	CB-H201
				94.04~07.08		BUSH-RR SUSPENSION ARM	CB-H401
ACCENT(INDIA)				99.06~		BUSH-RR SUSP RR ARM	CB-H215
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM(G)	CB-H052
				99.06~		BUSH-TRAILING ARM	CB-H214
				99.06~		BUSH-TRAILING ARM	CB-H213
				99.06~		BUSH-RR SUSPENSION ARM	CB-H212
ATOS				97.08~07.08		BUSH-LWR ARM RR	CB-H001
				94.04~99.12		BUSH-LWR ARM	CB-H001
				97.08~07.01	L	BUSH-ROD	CB-H004
				97.08~07.01	R	BUSH-ROD	CB-H005
				97.08~07.01		BUSH-TRAILING ARM	CB-H202
ATOS 01MY				97.08~07.01		BUSH-LWR ARM RR	CB-H001
				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				99.02~		BUSH-TRAILING ARM	CB-H202
ATOS PRIME 01MY				97.08~07.01		BUSH-LWR ARM RR	CB-H001
				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				99.02~		BUSH-TRAILING ARM	CB-H202
ATOS PRIME 06MY				97.08~07.01		BUSH-LWR ARM RR	CB-H001
				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				97.08~07.01		BUSH-TRAILING ARM	CB-H202
ATOS PRIME 99MY				98.10~07.08		BUSH-LWR ARM RR	CB-H001
				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				99.02~		BUSH-TRAILING ARM	CB-H202
ATOZ 98MY				97.08~07.08		BUSH-LWR ARM RR	CB-H001
				96.06~99.12		BUSH-LWR ARM	CB-H001
				97.08~07.01	L	BUSH-ROD	CB-H004
				97.08~07.01	R	BUSH-ROD	CB-H005
				97.08~07.01		BUSH-TRAILING ARM	CB-H202
AVANTE	BETA		GASOLINE	95.03~01.10		BUSH-RR SUSP RR ARM	CB-H209

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
	BETA,ALPHA BETA		GASOLINE GASOLINE	05.09~	RR	BUSHING	CB-K041
				95.03~01.10		BUSH-LWR ARM	CB-H006
				98.10~01.09		BUSH-LWR ARM	CB-H006
	05.12~		BUSH-RR SUSPENSION ARM	CB-K040			
	95.03~01.10		BUSH-RR SUSP FR ARM	CB-H404			
	95.03~01.10		ARM ASSY-RR SUSPENSION	CB-H222			
AVANTE 06MY							
				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
AVANTE HD							
				06.05~		BUSH-LWR ARM	CB-H064
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				83.07~		BUSH-FR LWR ARM A	CB-H069
				05.09~		BUSH-RUBBER	CB-K039
AVANTE XD							
	BETA		GASOLINE	00.03~		BUSH-LWR ARM	CB-H082
				04.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				00.03~02.03		BUSH-FR LWR ARM(G)	CB-H008
				02.03~02.07		BUSH-FR LWR ARM	CB-H008
				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				95.03~		BUSH-TRAILING ARM	CB-H402
AZERA							
				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
CENTENNIAL							
CLICK	G4AE,G4AE,,G4EC			92.09~08.11		BUSHING-UPR ARM	CB-H011
			GASOLINE	02.05~		BUSH-FR LWR ARM (A)	CB-H051
				91.10~07.06		BUSH-FR LWR ARM (A)	CB-H051
				02.05~		BUSH-FR LWR ARM(G)	CB-H070
COUPE 01MY							
				00.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				95.03~		BUSH-TRAILING ARM	CB-H402
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
COUPE 01MY(JAPAN)							
				00.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				95.03~		BUSH-TRAILING ARM	CB-H402
COUPE 07MY							
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
				95.03~		BUSH-TRAILING ARM	CB-H402
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
COUPE 07MY(JAPAN)							
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
				95.03~		BUSH-TRAILING ARM	CB-H402
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
COUPE 97MY	BETA BETA,ALPHA BETA						
			GASOLINE	95.03~01.10	RR	BUSH-RR SUSP RR ARM	CB-H209
				95.03~01.10		BUSH-LWR ARM	CB-H006
				98.10~01.09		BUSH-LWR ARM	CB-H006
			95.03~	BUSH-TRAILING ARM		CB-H402	
			95.03~01.10	BUSH-RR SUSP FR ARM		CB-H404	
			95.03~01.10	ARM ASSY-RR SUSPENSION		CB-H222	
DYNASTY							
				92.09~99.10		BUSHING-FR LWR ARM	CB-H033
				92.09~08.11		BUSHING-UPR ARM	CB-H011
				92.09~		BUSH-TRAILING ARM	CB-H203
ELANTRA							
				90.11~95.09	L L	BUSH-LWR ARM RR	CB-H018
				90.11~95.08		BUSH-RR	CB-H016
				93.05~95.09		BUSH-ROD	CB-H019

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
ELANTRA 00MY				90.11~95.08	R	BUSH-ROD	CB-H017
				93.05~95.09	R	BUSH-ROD	CB-H020
				90.11~95.09		BUSH-ARM	CB-H021
				00.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
ELANTRA 06MY				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
ELANTRA 91MY				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
				90.11~95.09		BUSH-LWR ARM RR	CB-H018
				90.11~95.08	L	BUSH-RR	CB-H016
				93.05~95.09	L	BUSH-ROD	CB-H019
ELANTRA 96MY	BETA BETA,ALPHA BETA		GASOLINE GASOLINE GASOLINE	90.11~95.08	R	BUSH-ROD	CB-H017
				93.05~95.09	R	BUSH-ROD	CB-H020
				90.11~95.09		BUSH-ARM	CB-H021
				95.03~01.10		BUSH-RR SUSP RR ARM	CB-H209
				95.03~01.10		BUSH-LWR ARM	CB-H006
ELANTRA(CHINA TAXI)	BETA BETA,ALPHA		GASOLINE GASOLINE	98.10~01.09		BUSH-LWR ARM	CB-H006
				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				95.03~01.10		BUSH-RR SUSP FR ARM	CB-H404
				95.03~01.10	RR	ARM ASSY-RR SUSPENSION	CB-H222
ELANTRA(CHINA)				00.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				95.03~		BUSH-TRAILING ARM	CB-H402
ELANTRA(INDIA)				00.03~		BUSH-LWR ARM RR	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				95.03~		BUSH-TRAILING ARM	CB-H402
ELANTRA(JAPAN)				00.03~		BUSHING-LWR ARM	CB-H082
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				95.03~		BUSH-TRAILING ARM	CB-H402
E-MIGHTY				03.03~		BUSH-STEEL & RUBBER	CB-H077
EQUUS				92.09~08.11		BUSHING-UPR ARM	CB-H011
EXCEL				89.04~94.04		BUSH-LWR ARM	CB-H022
				89.04~95.03	L	BUSH-RR	CB-H023
				85.02~89.12		BUSH	CB-H074
				89.04~95.03	R	BUSH-RR	CB-H042
GALLOPER				91.10~03.12		BUSH(A)	CB-H025
				92.01~03.12		BUSHING-LWR ARM	CB-H027
				92.01~00.05		BUSH-ARM	CB-H028
GALLOPER2				91.10~03.12		BUSH(A)	CB-H025
				92.01~03.12		BUSHING-LWR ARM	CB-H027
				92.01~00.05		BUSH-ARM	CB-H028
GETZ	G4AE,G4AE,G4EC		GASOLINE	02.05~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				02.05~02.12		BUSH-FR LWR ARM(G)	CB-H070
GETZ 05MY(INDIA)	G4AE,G4AE,G4EC		GASOLINE	02.05~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				02.05~		BUSH-FR LWR ARM(G)	CB-H070
GRACE	D4BA,D4BF,L4CS		DIESEL	88.01~04.01		BUSHING	CB-H030
						SHAFT BUSH BIG	CB-H062
	D4BA,D4BF,L4CS		DIESEL	88.04~04.10		BUSHING-UPR ARM.SMALL	CB-H029
				04.01~04.01		BUSHING-UPR ARM.SMALL	CB-H032
D4BA,D4BF,L4CS		DIESEL	88.04~97.01		SHAFT BUSH SMALL	CB-H063	
						BUSHING	CB-H084

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
GRANDEUR	D4BA,D4BF,L4CS		DIESEL	93.07~96.02		BUSHING	CB-H031
				95.10~03.12		BUSH-LWR ARM RR	CB-H031
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015
				00.08~06.12		BUSH-FR LWR ARM(G)	CB-H085
				98.03~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
				93.01~		BUSH-TRAILING ARM	CB-H203
GRANDEUR (NEW)				92.09~99.10		BUSHING-FR LWR ARM	CB-H033
				92.09~		BUSHING-UPR ARM	CB-H011
				92.09~		BUSH-TRAILING ARM	CB-H203
GRANDEUR Q20				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015
				04.08~		BUSH-FR LWR ARM(G)	CB-H085
				98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				93.01~		BUSH-TRAILING ARM	CB-H203
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603
				GRANDEUR Q25			
98.03~		BUSH-FR LWR ARM (A)	CB-H012				
98.03~		BUSH-FR LWR ARM(S)	CB-H013				
98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015				
00.08~06.12		BUSH-FR LWR ARM(G)	CB-H085				
98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204				
93.01~		BUSH-TRAILING ARM	CB-H203				
93.01~		BUSH-TRAILING ARM	CB-H203				
GRANDEUR TG				04.08~06.09		BUSH-UPR ARM	CB-H057
				06.05~		BUSH	CB-H056
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
GRANDEUR TG(JAPAN)				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
GRANDEUR XG				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015
				02.09~07.04		BUSH-FR LWR ARM(G)	CB-H085
				98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.09~		BUSHING-CROSSMEMBER CTR	CB-H207
				93.01~		BUSH-TRAILING ARM	CB-H203
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603
GRANDEUR XG (JAPAN)				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.12~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.09~06.05		BUSHING-CROSSMEMBER CTR	CB-H207
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				04.08~		BUSH-FR LWR ARM(G)	CB-H085
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.				
GRANDEUR XG25				93.01~		BUSH-TRAILING ARM	CB-H203				
				98.03~		BUSHING-TRAILING ARM (B)	CB-H403				
				98.03~		BUSH-UPR ARM	CB-H034				
				98.03~		BUSH-FR LWR ARM (A)	CB-H012				
				98.03~		BUSH-FR LWR ARM(S)	CB-H013				
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015				
				04.08~		BUSH-FR LWR ARM(G)	CB-H085				
				98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204				
				98.03~		BUSH-RR CTR ARM	CB-H205				
				98.03~		BUSH-RR ASSIST ARM	CB-H206				
				93.01~		BUSH-TRAILING ARM	CB-H203				
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603				
				GRANDEUR XG250				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
98.03~		BUSH-UPR ARM	CB-H034								
98.03~		BUSH-FR LWR ARM (A)	CB-H012								
98.03~		BUSH-FR LWR ARM(S)	CB-H013								
98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015								
04.08~		BUSH-FR LWR ARM(G)	CB-H085								
98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204								
98.03~		BUSH-RR CTR ARM	CB-H205								
98.03~		BUSH-RR ASSIST ARM	CB-H206								
93.01~		BUSH-TRAILING ARM	CB-H203								
98.03~		BUSH(B)-CROSSMEMBER	CB-H603								
GRANDEUR XG30								98.03~		BUSHING-TRAILING ARM (B)	CB-H403
								98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM (A)	CB-H012				
				98.03~		BUSH-FR LWR ARM(S)	CB-H013				
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015				
				04.08~		BUSH-FR LWR ARM(G)	CB-H085				
				98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204				
				98.03~		BUSH-RR CTR ARM	CB-H205				
				98.03~		BUSH-RR ASSIST ARM	CB-H206				
				93.01~		BUSH-TRAILING ARM	CB-H203				
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603				
				GRANDEUR XG300				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
								98.03~		BUSH-UPR ARM	CB-H034
98.03~		BUSH-FR LWR ARM (A)	CB-H012								
98.03~		BUSH-FR LWR ARM(S)	CB-H013								
98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015								
04.08~		BUSH-FR LWR ARM(G)	CB-H085								
98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204								
98.03~		BUSH-RR CTR ARM	CB-H205								
98.03~		BUSH-RR ASSIST ARM	CB-H206								
93.01~		BUSH-TRAILING ARM	CB-H203								
98.03~		BUSH(B)-CROSSMEMBER	CB-H603								
H-1 02MY	D4BF,L4CS,D4BH,D4BH		DIESEL					96.11~07.05		BUSH-LWR ARM FRT	CB-H048
								96.11~07.05		BUSH-LWR ARM RR	CB-H049
				96.11~07.05		BUSH-LWR ARM, RR	CB-H801				
				97.03~07.05		BUSH-LWR ARM, FRT	CB-H802				
				96.11~07.05		BUSH UPR-ARM	CB-H050				
				96.03~07.12		BUSH-LWR ARM RR	CB-H036				
				96.03~07.12		BUSH-LWR ARM	CB-H036				
				H-1 04MY	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM FRT	CB-H048
96.11~07.05		BUSH-LWR ARM RR	CB-H049								
96.11~07.05		BUSH-LWR ARM, RR	CB-H801								
97.03~07.05		BUSH-LWR ARM, FRT	CB-H802								
96.11~07.05		BUSH UPR-ARM	CB-H050								
96.03~07.12		BUSH-LWR ARM RR	CB-H036								
96.03~07.12		BUSH-LWR ARM	CB-H036								
H-1 98MY	D4BF,L4CS,D4BH,D4BH		DIESEL					96.11~07.05		BUSH-LWR ARM FRT	CB-H048
				96.11~07.05		BUSH-LWR ARM RR	CB-H049				
				96.11~07.05		BUSH-LWR ARM, RR	CB-H801				
				97.03~07.05		BUSH-LWR ARM, FRT	CB-H802				
				96.11~07.05		BUSH UPR-ARM	CB-H050				
				96.03~07.12		BUSH-LWR ARM RR	CB-H036				
				96.03~07.12		BUSH-LWR ARM	CB-H036				

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.12		BUSH-LWR ARM RR	CB-H036
H-100 (AU TRUCK)	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~		BUSH-LWR ARM	CB-H037
H-100 04MY	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~		BUSH-LWR ARM	CB-H037
H-100 04MY (TRUCK)	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~		BUSH-LWR ARM	CB-H037
H-100(MINI BUS)				93.07~96.02		BUSHING	CB-H031
	D4BA,D4BF,L4CS		DIESEL	95.10~03.12		BUSH-LWR ARM RR	CB-H031
H-100 (TRUCK)				88.05~97.03		BUSHING	CB-H035
HD11T POWER TRUCK				97.09~		STOPPER-BUMPER	CB-H078
HD11T TRUCK						STOPPER-BUMPER	CB-H078
HD160				97.09~		STOPPER-BUMPER	CB-H078
HD170				97.09~		STOPPER-BUMPER	CB-H078
HD23T POWER TRUCK						STOPPER-BUMPER	CB-H078
HD23T TRUCK				97.09~		STOPPER-BUMPER	CB-H078
HD310				97.09~		STOPPER-BUMPER	CB-H078
HD320				97.09~		STOPPER-BUMPER	CB-H078
HD370				97.09~		STOPPER-BUMPER	CB-H078
HD380				97.09~		STOPPER-BUMPER	CB-H078
HD45 04EM				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD450				97.09~		STOPPER-BUMPER	CB-H078
HD50				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD500				97.09~		STOPPER-BUMPER	CB-H078
HD60 98MY~04MY				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD600				97.09~		STOPPER-BUMPER	CB-H078
HD65 04EM				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD65 98MY~04MY				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD72 04MY				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD72 98-04MY				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD78 04EM				03.03~		BUSH-STEEL & RUBBER	CB-H077
HD8T POWER TRUCK						STOPPER-BUMPER	CB-H078
I30				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
I30 (JAPAN)				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
I30 CW				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
i30 CW(JAPAN)				05.09~		BUSHING	CB-K041
				06.05~		BUSH-FR LWR ARM A	CB-H069
				06.05~		BUSH-LWR ARM	CB-H064
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
GALLOPER INNOVATION				91.10~03.12		BUSH{A}	CB-H025
				92.01~03.12		BUSHING-LWR ARM	CB-H027
				92.01~00.05		BUSH-ARM	CB-H028
IX35				05.09~		BUSHING	CB-K041
IX35 10MY				05.09~		BUSHING	CB-K041
LAVITA				99.10~07.06		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
LAVITA 08MY				95.03~		BUSH-TRAILING ARM	CB-H402

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
LAVITA 09MY				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
LIBERO	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~		BUSH-LWR ARM	CB-H037
MARCIA				92.09~99.10		BUSHING-FR LWR ARM	CB-H033
				92.09~08.11		BUSHING-UPR ARM	CB-H011
				92.09~		BUSH-TRAILING ARM	CB-H203
MATRIX				95.03~		BUSH-TRAILING ARM	CB-H402
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
MATRIX 08MY				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
MATRIX 09MY				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				01.03~		BUSH-FR LWR ARM(G)	CB-H054
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
MIGHTY QT				03.03~		BUSH-STEEL & RUBBER	CB-H077
MIGHTY2				03.03~		BUSH-STEEL & RUBBER	CB-H077
MX ATOS		1.1		98.10~07.01	L	BUSH-ROD	CB-H004
		1.1		98.10~07.01	R	BUSH-ROD	CB-H005
		1.1		99.02~		BUSH-TRAILING ARM	CB-H202
		1.1		97.08~07.01		BUSH-LWR ARM RR	CB-H001
MX ATOS(MALAYSIA 1.1)				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				99.02~		BUSH-TRAILING ARM	CB-H202
				97.08~07.01		BUSH-LWR ARM RR	CB-H001
PORTER				88.05~97.03		BUSH SET-UPPER ARM	CS-H004
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.12		BUSHING	CB-H035
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~		BUSH-LWR ARM RR	CB-H036
	D4BB,D4BF,L4CS,D4BH		DIESEL	00.03~04.05		BUSH-LWR ARM	CB-H037
PORTER2				03.05~07.05		BUSH-LWR ARM	CB-H036
	D4BB,D4BF,D4BH,D4BH		DIESEL			BUSHING-UPR ARM,BIG	CB-H079
	D4BA,D4BB,D4BF,L4CS		DIESEL			BUSHING-UPR ARM,BIG	CB-H079
				96.03~		BUSH-LWR ARM	CB-H037
SANTA FE				00.12~		BUSH-FR LWR ARM{A}	CB-H038
				00.03~		BUSH-G LWR ARM	CB-H039
				00.02~		BUSH-TRAILING ARM	CB-H208
				04.08~		BUSHING-UPPER A RR	CB-H072
SANTA FE (NEW)				05.10~		BUSH-FR LWR ARM(G)	CB-H065
SANTA FE(JAPAN)				00.12~		BUSH-FR LWR ARM{A}	CB-H038
				00.03~		BUSH-G LWR ARM	CB-H039
				00.02~		BUSH-TRAILING ARM	CB-H208
SANTA FE04MY				04.08~		BUSHING-UPPER A RR	CB-H072
SANTA FE06MY				05.10~		BUSH-FR LWR ARM(G)	CB-H065
				04.08~		BUSHING-UPPER A RR	CB-H072
SANTA FE10MY				05.10~		BUSH-FR LWR ARM(G)	CB-H065
SANTAMO				98.03~02.12		BUSH-FR LWR ARM{A}	CB-K007
				96.01~04.11	L	BUSH-LWR ARM	CB-H040
				96.01~04.11	R	BUSH-LWR ARM	CB-H009
SANTRO				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005
				97.08~07.01		BUSH-TRAILING ARM	CB-H202
				98.10~07.08		BUSH-LWR ARM RR	CB-H001
SANTRO 06MY(INDIA)				98.10~07.01	L	BUSH-ROD	CB-H004
				98.10~07.01	R	BUSH-ROD	CB-H005

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.	
SANTRO 99MY(INDIA)				97.08-07.01		BUSH-TRAILING ARM	CB-H202	
				97.08-07.01		BUSH-TRAILING ARM	CB-H202	
				96.06-99.12		BUSH-LWR ARM	CB-H001	
				98.10-07.08		BUSH-LWR ARM RR	CB-H001	
SCOUPE				89.04-94.04		BUSH-LWR ARM	CB-H022	
				89.04-99.04	L	BUSH-RR	CB-H023	
				89.04-95.03	R	BUSH-RR	CB-H042	
SONATA				00.03~		BUSHING-LWR ARM	CB-H081	
				04.03~		BUSH-LWR ARM RR	CB-H082	
				88.06-93.09		BUSH-LWR ARM	CB-H043	
				92.09-99.10		BUSHING-FR LWR ARM	CB-H033	
				88.06-95.04	L	BUSH-ROD	CB-H045	
				93.04-93.04	R	BUSH-ROD	CB-H047	
				92.04-95.04	R	BUSH-ROD	CB-H046	
				92.09-08.11		BUSHING-UPR ARM	CB-H011	
				88.06-93.09		BUSH-ARM	CB-H044	
				92.09~		BUSH-TRAILING ARM	CB-H203	
SONATA (INDIA)				98.03~		BUSHING-TRAILING ARM (B)	CB-H403	
				98.03~		BUSH-RR CTR ARM	CB-H205	
				98.03~		BUSH-RR ASSIST ARM	CB-H206	
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603	
				98.03~		BUSH-UPR ARM	CB-H034	
				98.12~		BUSH-FR LWR ARM (A)	CB-H012	
				98.03~		BUSH-FR LWR ARM(S)	CB-H013	
				04.08~		BUSH-FR LWR ARM(G)	CB-H085	
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204	
				93.01~		BUSH-TRAILING ARM	CB-H203	
	SONATA 02MY				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
					98.03~		BUSH-RR CTR ARM	CB-H205
					98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603	
				98.03~		BUSH-UPR ARM	CB-H034	
				98.12~		BUSH-FR LWR ARM (A)	CB-H012	
				98.03~		BUSH-FR LWR ARM(S)	CB-H013	
				04.08~		BUSH-FR LWR ARM(G)	CB-H085	
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204	
				93.01~		BUSH-TRAILING ARM	CB-H203	
SONATA 09MY				04.08~		BUSH-FR LWR ARM(G)	CB-H085	
SONATA 91MY				88.06-93.09		BUSH-LWR ARM	CB-H043	
				88.06-95.04	L	BUSH-ROD	CB-H045	
				92.04-98.06	R	BUSH-ROD	CB-H046	
				88.06-93.09		BUSH-ARM	CB-H044	
SONATA 94MY				88.06-95.04	L	BUSH-ROD	CB-H045	
				92.04-95.04	R	BUSH-ROD	CB-H046	
				92.09-08.11		BUSHING-UPR ARM	CB-H011	
				92.09~		BUSH-TRAILING ARM	CB-H203	
				92.09-99.10		BUSHING-FR LWR ARM	CB-H033	
SONATA 99MY				98.03~		BUSHING-TRAILING ARM (B)	CB-H403	
				98.03~		BUSH-FR LWR ARM(S)	CB-H013	
				98.03~		BUSH-RR CTR ARM	CB-H205	
				98.03~		BUSH-RR ASSIST ARM	CB-H206	
				92.09~		BUSH-TRAILING ARM	CB-H203	
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603	
				98.03~		BUSH-UPR ARM	CB-H034	
				98.12~		BUSH-FR LWR ARM (A)	CB-H012	
				98.03-00.08		BUSH-FR LWR ARM(G)	CB-H015	
				00.08-06.12		BUSH-FR LWR ARM(G)	CB-H085	
				98.03-00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204	
				98.03-98.12		BUSH-FR LWR ARM (A)	CB-H012	
SONATA EF				98.03~		BUSHING-TRAILING ARM (B)	CB-H403	
				98.03~		BUSH-UPR ARM	CB-H034	
				98.03~		BUSH-FR LWR ARM (A)	CB-H012	

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015
				98.09~02.07		BUSH -FR LWR ARM	CB-H066
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
				98.03~00.07		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
						BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603
				92.09~		BUSH-TRAILING ARM	CB-H203
SONATA NF				04.08~		BUSHING-TRAILING ARM B	CB-H405
				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-FR LWR ARMA	CB-H055
				04.08~		BUSH-FR LWR ARMS	CB-H059
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSH-RR CTR ARM	CB-H218
						BUSHING-UPPER A RR	CB-H072
				04.08~		BUSH-TRAILING ARM	CB-H216
SONATA NF (JAPAN)				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSHING-UPPER A RR	CB-H072
SONATA NF 04MY				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
SONATA NF 04MY(INDIA)				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
SONATA NF 08MY				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				04.08~		BUSHING-UPPER A RR	CB-H072
SONATA NF 09MY(INDIA)				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
SONATA NF(CHINA)				04.08~06.09		BUSH-UPR ARM	CB-H057
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
SONATA YF 10MY				05.09~		BUSHING	CB-K041
SONATA(CHINA TAXI)				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603
				98.03~		BUSH-UPR ARM	CB-H034
				98.12~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				04.08~		BUSH-FR LWR ARM(G)	CB-H085
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204
				93.01~		BUSH-TRAILING ARM	CB-H203
SONATA(CHINA)				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603
				98.03~		BUSH-UPR ARM	CB-H034
				98.12~		BUSH-FR LWR ARM (A)	CB-H012
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				04.08~		BUSH-FR LWR ARM(G)	CB-H085
				00.04~		BUSH-PILLOW BALL,RR UPR ARM	CB-H204

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
SPORTAGE (NEW)				93.01~		BUSH-TRAILING ARM	CB-H203
				00.03~		BUSH-LWR ARM RR	CB-H082
				04.03~		BUSH-FR LWR ARM(G)	CB-H086
				83.07~86.12		BUSH-ARM LWR FR	CB-H014
STAREX				03.05~07.05		BUSHING, UPPER ARM, BIG	CB-H079
	D4BB,D4BF,D4BH,D4BH		DIESEL			BUSHING, UPPER ARM, BIG	CB-H079
	D4BB,D4BF,D4BH,D4BH		DIESEL	01.07~01.07		BUHSING, UPPER ARM, SMALL	CB-H073
				04.01~07.05		BUSHING	CB-H071
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.01		BUSH-LWR ARM RR	CB-H036
	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM FRT	CB-H048
	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM RR	CB-H049
	D4BB,D4BF,L4CS,D4BH		DIESEL	00.03~04.05		BUSH-LWR ARM	CB-H036
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM, RR	CB-H801
	D4BB,D4BF,L4CS,D4BH		DIESEL	97.03~07.05		BUSH-LWR ARM, FRT	CB-H802
	D4BH,D4BH		DIESEL	96.11~07.05		BUSH UPR-ARM	CB-H050
	STAREX 02MY	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM FRT
D4BF,L4CS,D4BH,D4BH			DIESEL	96.11~07.05		BUSH-LWR ARM RR	CB-H049
D4BB,D4BF,L4CS,D4BH			DIESEL	96.11~07.05		BUSH-LWR ARM, RR	CB-H801
D4BB,D4BF,L4CS,D4BH			DIESEL	97.03~07.05		BUSH-LWR ARM, FRT	CB-H802
D4BH,D4BH			DIESEL	96.11~07.05		BUSH UPR-ARM	CB-H050
				03.05~07.05		BUSHING-UPR ARM,BIG	CB-H079
D4BA,D4BB,D4BF,L4CS			DIESEL	96.03~07.12		BUSH-LWR ARM RR	CB-H036
D4BB,D4BF,L4CS,D4BH			DIESEL			BUSH-LWR ARM	CB-H036
STAREX 97MY	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM FRT	CB-H048
	D4BF,L4CS,D4BH,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM RR	CB-H049
	D4BB,D4BF,L4CS,D4BH		DIESEL	96.11~07.05		BUSH-LWR ARM, RR	CB-H801
	D4BB,D4BF,L4CS,D4BH		DIESEL	97.03~07.05		BUSH-LWR ARM, FRT	CB-H802
	D4BH,D4BH		DIESEL	96.11~07.05		BUSH UPR-ARM	CB-H050
	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~07.12		BUSH-LWR ARM RR	CB-H036
STELLA		1.4 / 1.6		86.10~96.10		BUSH-LWR ARM RR	CB-H076
				06.05~		BUSH-FR LWR ARM A	CB-H069
				83.07~96.10		BUSH-PILLOW BALL RR UPR ARM	CB-H223
		1.4 / 1.6		01.03~		BUSH-RR SUSPENSION ARM	CB-H223
		1.4 / 1.6		83.07~96.10		BUSH-ARM LWR FR	CB-H069
				04.03~		BUSH-FR LWR ARM(G)	CB-H086
STELLA (NEW)				83.07~96.10	FR	BUSH-RR SUSPENSION UPR(BIG)	CB-H219
				84.01~86.03		BUSH-FR LWR ARM	CB-H014
TB(JAPAN)				02.05~		BUSH-FR LWR ARM(G)	CB-H070
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
TIBURON	BETA		GASOLINE	95.03~01.10		BUSH-RR SUSP RR ARM	CB-H209
	BETA		GASOLINE	95.03~01.10		BUSH-RR SUSP FR ARM	CB-H404
	BETA,ALPHA		GASOLINE	95.03~01.10	RR	ARM ASSY-RR SUSPENSION	CB-H222
TRAJET				99.10~07.06	IN	BUSH-SUSPENSION ARM	CB-H210
				00.01~07.06	OUT	BUSH-SUSPENSION ARM	CB-H211
				99.10~07.06		BUSH-FR LWR ARM (A)	CB-H051
TRAJET XG	G4AE,G4AE,G4EC		GASOLINE	02.05~		BUSH-FR LWR ARM A	CB-H051
				99.06~		BUSH-FR LWR ARM A	CB-H051
				99.10~07.06		BUSH-FR LWR ARM (G)	CB-H083
				99.10~07.06	IN	BUSH-SUSPENSION ARM	CB-H210
				99.10~07.06	OUT	BUSH-SUSPENSION ARM	CB-H211
				99.10~07.06		BUSH-FR LWR ARM (G)	CB-H083
TRAJET(JAPAN)				99.10~07.06	IN	BUSH-SUSPENSION ARM	CB-H210
				99.10~07.06	OUT	BUSH-SUSPENSION ARM	CB-H211
				99.10~04.02		BUSH-FR LWR ARM (G)	CB-H083
TUCSON				00.03~		BUSHING-LWR ARM	CB-H081
				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				83.07~86.12		BUSH-FR LWR ARM	CB-H014
				04.03~		BUSH-LWR ARM RR	CB-H082
				04.03~		BUSH-FR LWR ARM(G)	CB-H086
TUCSON 10MY				05.09~		BUSHING	CB-K041
TUCSON(CHINA)				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				04.03~		BUSH-LWR ARM RR	CB-H082
				04.03~		BUSH-FR LWR ARM(G)	CB-H086

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
TUCSON(INDIA)				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				04.03~		BUSH-LWR ARM RR	CB-H082
				04.03~		BUSH-FR LWR ARM(G)	CB-H086
TUCSON(JAPAN)				95.03~		BUSH-TRAILING ARM(BIG)	CB-H402
				04.03~		BUSH-LWR ARM RR	CB-H082
				04.03~		BUSH-FR LWR ARM(G)	CB-H086
TUSCANI	BETA		GASOLINE	01.03~		BUSH-FR LWR ARM(G)	CB-H054
				00.03~02.03		BUSH-FR LWR ARM(G)	CB-H008
				02.03~02.07		BUSH-FR LWR ARM(G)	CB-H008
				03.10~		BUSH-FR LWR ARM	CB-K033
				83.07~96.10		BUSH-PILLOW BALL, RR UPR ARM	CB-H220
				01.03~		BUSH-RR SUSPENSION ARM	CB-H223
VERNA	G4AE,G4AE,G4EC		GASOLINE	99.06~		BUSH-RR SUSP RR ARM	CB-H215
				02.05~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM (A)	CB-H051
				99.06~		BUSH-FR LWR ARM(G)	CB-H052
				99.10~07.06		BUSH-FR LWR ARM(G)	CB-H083
				99.06~		BUSH-TRAILING ARM	CB-H214
				99.06~		BUSH-TRAILING ARM	CB-H213
				99.06~		BUSH-RR SUSPENSION ARM	CB-H212
				VERNA (BL-NEW)			
00.08~07.04	BUSH-FR LWR ARM(G)	CB-H085					
06.05~	BUSH	CB-H056					
04.08~	BUSH-FR LWR ARM(G)	CB-H056					
VERNA (HYBRID)				05.02~		BUSH-FR LWR ARMA	CB-K032
				06.05~		BUSH	CB-H056
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
VERNA 06MY				05.02~		BUSH-FR LWR ARMA	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
VERNA 06MY(INDIA)				05.02~		BUSH-FR LWR ARMA	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056

KIA

BESTA				95.10~05.10		BUSH-ARM LWR	CB-K012
				95.10~05.10		BUSH-UPR ARM	CB-K004
						BUSH-FORK	CB-K013
				00.01~04.04		BUSH - LWR.ARM	CB-K014
				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K002
				92.07~04.09		BUSH	CB-K003
				91.01~99.12		BUSH,RUBBER LOWER AR	CB-K001
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K002
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K003
BONGO FRONTIER 1T				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K002
				92.07~04.09		BUSH	CB-K003
				91.01~99.12		BUSH,RUBBER LOWER AR	CB-K001
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K002
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K003
BONGO(POWER)				99.12~99.12		LOWER ARM BUSH	CB-K042
BONGO(WIDE)				95.10~05.10		BUSH-UPR ARM	CB-K004
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K002
				92.07~04.09		BUSH	CB-K003
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K002
				91.01~99.12		BUSH,RUBBER UPPER AR	CB-K003

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
BONG03		2.9		98.06~		BUSH	CB-K201
			93.06~03.06		BUSH-FORK	CB-K013	
			95.10~05.10		BUSH-ARM LWR	CB-K012	
			95.10~05.10		BUSH-UPR ARM	CB-K004	
			00.01~04.04		BUSH - LWR.ARM	CB-K014	
			04.01~		BUSH	CB-K029	
			04.01~		BUSHING	CB-K028	
			04.01~		BUSHING	CB-K027	
	BORREGO				04.08~		BUSHING-TRAILING ARM B
CAPITAL	FE,F8		GASOLINE	92.04~05.04	R	BUSH RUBBER FRT RH	CB-K011
					L	BUSH RUBBER FRT LH	CB-K011
	FE,F8		GASOLINE	92.04~05.04	L	BUSH RUBBER FRT LH	CB-K011
CARENS				99.01~06.08		BUSH-RUBBER	CB-K025
				05.09~		BUSHING	CB-K041
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
CARENS 00MY			99.01~06.08		BUSH-RUBBER	CB-K025	
CARENS 06MY				05.09~		BUSHING	CB-K041
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
CARENS2			99.01~06.08		BUSH-RUBBER	CB-K025	
CARENS2 02MY			99.01~06.08		BUSH-RUBBER	CB-K025	
CARNIVAL				~99.12		BUSH-ARMLWR	CB-K005
				~99.12		BUSH-ARMLWR	CB-K006
CARSTAR				98.03~02.12		BUSH-FR LWR ARM{A}	CB-K007
				96.01~04.11	L	BUSH LWR ARM LH	CB-H040
				96.01~04.11	R	BUSH-LWR ARM RH	CB-H009
CERATO			03.10~		BUSH-FR LWR ARM(G)	CB-K033	
CERATO 04MY				00.03~		BUSHING-LWR ARM	CB-H081
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
CERATO 06MY				00.03~		BUSHING-LWR ARM	CB-H081
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
CERATO SX				00.03~		BUSHING-LWR ARM	CB-H081
				03.10~		BUSH-FR LWR ARM(G)	CB-K033
CLARUS				~00.04	R	LWR.ARM BUSH REAR RH	CB-K009
				~00.04	L	LWR.ARM BUSH REAR LH	CB-K008
CONCORD	FE,F8		GASOLINE	92.04~05.04	R	BUSH RUBBER FRT RH	CB-K011
					R	BUSH RUBBER FRT LH	CB-K011
	FE,F8			GASOLINE	92.04~05.04	L	BUSH RUBBER FRT LH
CREDOS		1.8 / 2.0		~00.04	L	LWR.ARM BUSH REAR RH	CB-K009
			95.10~00.10		BUSH-RUBBER.FRT	CB-K010	
			~00.04	L	LWR.ARM BUSH REAR LH	CB-K008	
CREDOS2				~00.04	R	LWR.ARM BUSH REAR RH	CB-K009
				95.10~00.10		BUSH-RUBBER.FRT	CB-K010
				~00.04	L	LWR.ARM BUSH REAR LH	CB-K008
FRONTIER				97.04~		BUSH-ARM.LWR	CB-K001
				92.07~02.02		BUSH-LWR.ARM RUBBER	CB-K001
				91.01~99.12		BUSH,RUBBER LOWER AR	CB-K001
FRONTIER 1.3T			98.06~		BUSH	CB-K201	
JOICE				98.03~02.12		BUSH-FR LWR ARM{A}	CB-K007
				98.03~02.12	L	BUSH LWR ARM LH	CB-H040
				98.03~02.12	R	BUSH-LWR ARM RH	CB-H009
K2500				98.06~		BUSH	CB-K201
				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K003
				04.01~		BUSH	CB-K029
				04.01~		BUSHING	CB-K028
				04.01~		BUSHING	CB-K027
K2500 04MY			97.04~		BUSH-ARM.LWR	CB-K001	
K2700				98.06~		BUSH	CB-K201
				92.07~02.02		BUSH-ARM.LWR	CB-K001

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K003
				04.01~		BUSH	CB-K029
				04.01~		BUSHING	CB-K028
				04.01~		BUSHING	CB-K027
K2700 04MY				97.04~		BUSH-ARM.LWR	CB-K001
K2700±				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K003
K2900				98.06~		BUSH	CB-K201
				04.01~		BUSH	CB-K029
				04.01~		BUSHING	CB-K028
				04.01~		BUSHING	CB-K027
K2900 04MY				97.04~		BUSH-ARM.LWR	CB-K001
K3000				98.06~		BUSH	CB-K201
				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K003
K3000±				92.07~02.02		BUSH-ARM.LWR	CB-K001
				92.07~04.09		BUSH-REAR RUBBER	CB-K002
				92.07~04.09		BUSH	CB-K003
K3000S				98.06~		BUSH	CB-K201
				04.01~		BUSH	CB-K029
				04.01~		BUSHING	CB-K028
				04.01~		BUSHING	CB-K027
K3000S 04MY				97.04~		BUSH-ARM.LWR	CB-K001
K4000S				98.06~		BUSH	CB-K201
K4000S 04MY				98.06~		BUSH	CB-K201
				97.04~		BUSH-ARM.LWR	CB-K001
				04.01~		BUSH	CB-K029
				04.01~		BUSHING	CB-K028
				04.01~		BUSHING	CB-K027
LOTZE				05.09~		BUSHING	CB-K041
				00.03~		BUSHING-LWR ARM	CB-H081
				04.03~		BUSH-LWR ARM RR	CB-H082
				06.03~		BUSHING-LWR ARM	CB-K036
				05.09~		BUSH	CB-K030
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
MAGENTIS 00MY				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
				00.04~		BUSH-PILLOW BALL RR UPR ARM	CB-H204
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				92.09~		BUSH-TRAILING ARM	CB-H203
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603
MAGENTIS 06MY				05.09~		BUSHING	CB-K041
				04.03~		BUSH-LWR ARM RR	CB-H082
				06.03~		BUSHING-LWR ARM	CB-K036
				05.09~		BUSH	CB-K030
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039
MAGENTIS 09MY				05.09~		BUSHING	CB-K041
				06.03~		BUSHING-LWR ARM	CB-K036
				05.09~		BUSH	CB-K030
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
MENTOR				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
MENTOR2				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
MOHAVE				04.08~		BUSHING-TRAILING ARM B	CB-H405
MORNING				04.01~		BUSH-FR LWR ARM A	CB-K034
				04.01~		BUSH-FR LWR ARM(G)	CB-K037
NEW SPORTAGE				04.03~		BUSH-LWR ARM RR	CB-H082
				95.03~		BUSH-TRAILING ARM	CB-H402
OPIRUS				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				04.08~		BUSHING-TRAILING ARM B	CB-H405
				04.08~		BUSH-FR LWR ARMA	CB-H055
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~		BUSH-RR CTR ARM	CB-H205
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				98.09~06.05		BUSHING-CROSSMEMBER CTR	CB-H207
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
				OPIRUS 03MY			
98.03~		BUSH-FR LWR ARM(S)	CB-H013				
98.03~		BUSH-RR CTR ARM	CB-H205				
98.09~06.05		BUSHING-CROSSMEMBER CTR	CB-H207				
OPIRUS 06MY				04.08~		BUSHING-TRAILING ARM B	CB-H405
				04.08~		BUSH-FR LWR ARMA	CB-H055
				06.05~		BUSH	CB-H056
				04.08~		BUSH-RR CTR ARM	CB-H218
				04.08~		BUSHING-UPPER A RR	CB-H072
				04.08~08.12		BUSH-TRAILING ARM	CB-H216
OPTIMA				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				98.03~00.08		BUSH-FR LWR ARM(G)	CB-H015
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
				06.05~		BUSH	CB-H056
				04.08~		BUSH-FR LWR ARM(G)	CB-H056
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				92.09~		BUSH-TRAILING ARM	CB-H203
				93.01~		BUSH-TRAILING ARM	CB-H203
98.03~		BUSH{B}-CROSSMEMBER	CB-H603				
OPTIMA 00MY				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
				00.04~		BUSH-PILLOW BALL RR UPR ARM	CB-H204
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				92.09~		BUSH-TRAILING ARM	CB-H203
				98.03~		BUSH{B}-CROSSMEMBER	CB-H603
OPTIMA 06MY				05.09~		BUSHING	CB-K041
				04.03~		BUSH-LWR ARM RR	CB-H082
				06.03~		BUSHING-LWR ARM	CB-K036
				05.09~		BUSH	CB-K030
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
05.09~		BUSH-RUBBER	CB-K039				
OPTIMA 09MY				05.09~		BUSHING	CB-K041
				06.03~		BUSHING-LWR ARM	CB-K036
				05.09~		BUSH	CB-K030
				05.12~		BUSH-RR SUSPENSION ARM	CB-K040
				05.09~		BUSH-RR SUSPENSION ARM	CB-K038
				05.09~		BUSH-RUBBER	CB-K039

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
PAMAX				03.03~		BUSH-STEEL & RUBBER	CB-H077
PICANTO 04MY				04.01~		BUSH-FR LWR ARM A	CB-K034
PICANTO 06MY				04.01~		BUSH-FR LWR ARM A	CB-K034
				04.01~		BUSH-FR LWR ARM(G)	CB-K037
PICANTO 08MY				04.01~		BUSH-FR LWR ARM A	CB-K034
				04.01~		BUSH-FR LWR ARM(G)	CB-K037
PREGIO				93.06~05.10		BUSH-FORK	CB-K013
				95.10~05.10		BUSH-ARM LWR	CB-K012
				95.10~05.10		BUSH-UPR ARM	CB-K004
				00.01~04.04		BUSH - LWR.ARM	CB-K014
				04.01~05.10		BUSH-ARM LWR	CB-K210
PRIDE (JB)				05.02~		BUSH-FR LWR ARM A	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
PRIDE HYBRID				05.02~		BUSH-FR LWR ARM A	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
REGAL				98.03~		BUSHING-TRAILING ARM (B)	CB-H403
				98.03~		BUSH-UPR ARM	CB-H034
				98.03~		BUSH-FR LWR ARM(S)	CB-H013
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
				00.08~07.04		BUSH-FR LWR ARM(G)	CB-H085
				98.03~		BUSH-PILLOW BALL RR UPR ARM	CB-H204
				98.03~		BUSH-RR CTR ARM	CB-H205
				98.03~		BUSH-RR ASSIST ARM	CB-H206
				98.03~		BUSH(B)-CROSSMEMBER	CB-H603
RETONA				93.06~99.02		BUSH-LWR.ARM	CB-K019
	RF-TCI,HW,FE		DIESEL	97.11~03.06		BUSH-LWR.ARM	CB-K019
				93.06~00.09		BUSH LWR ARM	CB-K021
	RF-TCI,HW,FE		DIESEL	97.11~03.06		BUSH LWR ARM	CB-K021
				93.06~03.06		BUSH UP.ARM	CB-K022
				93.06~00.09		BUSH-FORK	CB-K013
	FE		DIESEL	~05.10		BUSH-FORK	CB-K013
	RF-TCI,HW,FE		DIESEL			BUSH-FORK	CB-K013
RIO				99.10~02.09		BUSH-RUBBER	CB-K015
	A3E,A5E,A5D		GASOLINE	~99.11		BUSH-RUBBER	CB-K026
	A3E,A5E,A5D		GASOLINE	02.06~05.06		BUSH-RUBBER	CB-K016
RIO 00MY				99.11~00.02		BUSH-RUBBER	CB-K202
	A3E,A5E,A5D		GASOLINE	99.11~02.09		BUSH-RUBBER	CB-K015
	A3E,A5E,A5D		GASOLINE	99.11~02.09		BUSH-RUBBER	CB-K600
	A3E,A5E,A5D		GASOLINE	02.06~05.06		BUSH-RUBBER	CB-K016
RIO 05MY				05.02~		BUSH-FR LWR ARM A	CB-K032
				05.02~		BUSH-FR LWR ARM(G)	CB-H056
SEPHIA	B5		GASOLINE	93.06~99.12	R	BUSH-RR.LWR.ARM,RH	CB-K018
					L	BUSH-LWR ARM.RR.LH	CB-K017
	B5		GASOLINE	93.06~99.12	L	BUSH-LWR ARM.RR.LH	CB-K017
				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
				93.06~99.12		RUBBER BUSH	CB-K023
SEPHIA2				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
SHUMA				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
SHUMA2				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
SORENTO				02.01~09.08		BALL JOINT ASSY-LWR ARM	CJ-K014
SORENTO 03MY				02.10~06.06		BALL JOINT ASSY-LWR ARM	CJ-K014
SORENTO 06MY				06.03~09.08		BALL JOINT ASSY-LWR ARM	CJ-K014
SOUL				05.02~		BUSH-FR LWR ARM A	CB-K032
SPECTRA				93.06~99.12		RUBBER BUSH	CB-K023
				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
SPECTRAWING				~99.06		RUBBER BUSH-LWR.ARM	CB-K024
				99.01~06.08		BUSH-RUBBER	CB-K025
SPORTAGE				93.06~03.06		BUSH-LWR.ARM	CB-K019
				93.06~00.09		BUSH-UP.ARM	CB-K020
				93.06~03.06		BUSH LWR ARM	CB-K021
				93.06~03.06		BUSH UP.ARM	CB-K022
				93.06~03.06		BUSH-FORK	CB-K013
				95.03~		BUSH-TRAILING ARM	CB-H402
SPORTAGE (NEW)				95.03~		BUSH-TRAILING ARM	CB-H402
SPORTAGE 10MY				05.09~		BUSHING	CB-K041
TITAN(WIDE LOW)				98.06~		BUSH	CB-K201
TOPIC				91.01~02.02		BUSH-ARM.LWR	CB-K001
				91.01~04.09		BUSH-REAR RUBBER	CB-K002
				91.01~04.09		BUSH	CB-K003
VISTO				97.08~07.01	L	BUSH-ROD LH	CB-H004
				97.08~07.01	R	BUSH-ROD RH	CB-H005
				97.08~07.01		BUSH-TRAILING ARM	CB-H202

GM DAEWOO

CIELO						BLOCK-PWR UNIT DAMPING,FR	CB-D004
						BUSH-DAMPING	CB-D004
						BUSH	CB-D004
						BUSH-DMP	CB-D004
DAMAS/LABO						BUSHING-FRONT SPNSN ARM	CB-D015
						BUSHING-CONTROL ARM	CB-D015
GENTRA(T250)						BUSHING-CONTROL ARM	CB-D002
						BUSH-DAMPING	CB-D002
KALOS(T200)						BUSH	CB-D701
						BUSH-CONTROL ARM.FRONT	CB-D001
						BUSH-CONT ARM	CB-D002
						BUSH-DAMPING	CB-D002
LACETTI(J200)	FAM1,FAM2 FAM1					BUSH-DMP	CB-D003
						JOINT SET-BALL .CONT ARM	CJ-D006
LANOS(T100)						BLOCK-PWR UNIT DAMPING,FR	CB-D004
						BUSH-DAMPING	CB-D004
						BUSH	CB-D004
						BUSH-DMP	CB-D004
LEGANZA(V100)	FAM1,FAM2 FAM1,FAM2					BUSH-DMP	CB-D006
						BUSH-CONTROL ARM.RR	CB-D007
LEMAN						BLOCK-PWR UNIT DAMPING,FR	CB-D004
						BUSH-DAMPING	CB-D004
						BUSH	CB-D004
						BUSH-DMP	CB-D004
MAGNUS(V200)						BUSH-FRT	CB-D008
						BUSH - RR UPR ARM	CB-D209
MATIZ(M100)						BUSH - REACTION ROD A	CB-D206
						BUSHING-CONTROL ARM	CB-D009
MX ATOS(MALAYSIA 1.1)						DAMPING BUSH A-FRT,C/ARM	CB-D011
						DAMPING BUSH A-FRT,C/ARM(49mm)	CB-D011
						DAMPING BUSH	CB-D011
NUBIRA(J100)						DAMPING BUSH A-RR,C/ARM/	CB-D010
PRINCE						BUSHING DAMPER C/ARM	CB-D012
						BUSHING-DAMPING	CB-D207
						DAMPING BUSH A-LWR	CB-D208
						BUSH-CONTROL ARM DAMPING	CB-D014
						BUSH-CONTROL ARM DAMPING	CB-D013
						BUSH-RR LOWER DAMPING	CB-D205
REZZO(U100)	FAM2					BUSH-RR	CB-D013
						BUSH-CONT ARM	CB-D014

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
TICO						BUSH-DMP	CB-D013
						BUSHING-FRONT SPNSN ARM	CB-D015
						BUSH T/ARM RR-SMALL	CB-D202
						BUSH T/ARM RR-BIG	CB-D201
						BUSH-REAR TRAILING ARM	CB-D202
						BUSH-REAR TRAILING ARM RE	CB-D201
BUSHING-CONTROL ARM	CB-D015						

SSANGYONG

FAMILY						BUSHING-S/ABS UPR	CB-S203
						BUSHING-FRT LWR SUSP	CB-S004
						BUSHING-STRUT BAR	CB-S204
KORANDO						BUSHING-SPRING	CB-S201
MUSSO						BUSHING-SPRING SHACKLE	CB-S202
						BUSHING-FRT LWR ARM RR	CB-S002
NEW KORANDO	OM661,OM662,E32 OM661,OM662,E32		DIESEL DIESEL			BUSHING-FRT LWR ARM RR	CB-S002
						BUSHING-FRT LWR ARM RR	CB-S002
						BUSHING-FRT UPR ARM	CB-S003
						BUSHING-FRT LWR ARM	CB-S005

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
END ASSY - TIE ROD / RACK							
HYUNDAI							
5TON CLASS TRUCK				93.01~	L	END ASSY-TIE ROD LH(5T,OLD)	CT-H022
				98.05~	L	END ASSY-TIE ROD LH	CT-H020
				93.01~	R	END ASSY-TIE ROD RH(5T,OLD)	CT-H023
				97.12~98.05	R	END ASSY-TIE ROD RH/98MY	CT-H021
				98.05~	R	END ASSY-TIE ROD RH	CT-H021
ACCENT				89.07~99.10		ROD ASSY-TIE	CT-H001
				89.07~95.03		BALL JOINT ASSY-INR	CT-H001
				99.06~07.02		BALL JOINT ASSY-INR	CT-H027
				93.07~03.12		ROD ASSY-TIE.INNER	CT-H001
				90.12~07.08		END ASSY-TIE ROD	CT-H013
	BETA		GASOLINE	91.04~01.11		END ASSY-TIE ROD	CT-H013
				96.11~07.12		JOINT ASSY-INNER BALL	CT-H001
ACCENT 00MY				90.12~07.08		END ASSY-TIE ROD	CT-H013
ACCENT 01MY				99.06~07.02		BALL JOINT ASSY-INR	CT-H027
ACCENT 95MY	BETA		GASOLINE	91.04~01.08		END ASSY-TIE ROD	CT-H013
				90.12~07.08		END ASSY-TIE ROD	CT-H013
				93.07~99.10		ROD ASSY-TIE	CT-H001
AERO TOWN				93.01~	L	END ASSY-TIE ROD LH(5T,OLD)	CT-H022
				93.01~	R	END ASSY-TIE ROD RH(5T,OLD)	CT-H023
ATOS				97.08~07.01		END ASSY-TIE ROD	CT-H002
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
ATOS 01MY				97.08~07.01		END ASSY-TIE ROD	CT-H002
				92.09~07.08		END ASSY-TIE ROD	CT-H013
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
ATOS PRIME 01MY				97.08~07.01		END ASSY-TIE ROD	CT-H002
				92.09~07.08		END ASSY-TIE ROD	CT-H013
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
ATOS PRIME 06MY				97.08~07.01		END ASSY-TIE ROD	CT-H002
				92.09~07.08		END ASSY-TIE ROD	CT-H013
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
ATOS PRIME 99MY				97.08~07.01		END ASSY-TIE ROD	CT-H002
				92.09~07.08		END ASSY-TIE ROD	CT-H013
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
AT0Z				97.08~07.01		END ASSY-TIE ROD	CT-H002
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
AT0Z 98MY				97.08~07.01		END ASSY-TIE ROD	CT-H002
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029
AVANTE	BETA		GASOLINE	95.03~98.04		JOINT ASSY-INNER BALL	CT-H012
				98.04~01.10		JOINT ASSY-INNER BALL	CT-H012
AVANTE XD				00.03~		JOINT ASSY-INNER BALL	CT-H028
AZERA				04.08~	L	END ASSY-TIE ROD LH	CT-H030
				04.08~	R	END ASSY-TIE ROD RH	CT-H031
AZERA				04.08~		JOINT ASSY-INNER BALL	CT-H038
CENTENNIAL				90.12~		END ASSY-TIE ROD	CT-H013
CHORUS				92.01~04.01	L	END ASSY-TIE ROD LH	CT-H025
	D4AF,D4AE		DIESEL	92.01~02.11	R	END ASSY-TIE ROD RH	CT-H026
				04.01~04.01	R	END ASSY-TIE ROD RH	CT-H026
CLICK				99.03~		END ASSY-TIE ROD	CT-H013
COUNTY	D4AL,D4DA,D4AF		DIESEL	98.03~	L	END ASSY-TIE ROD LH	CT-H034
	D4AL,D4DA,D4AF		DIESEL	98.03~	R	END ASSY-TIE ROD RH	CT-H035
				98.10~	R	END ASSY-TIE ROD RH	CT-H035
COUPE 01MY				90.12~		END ASSY-TIE ROD	CT-H013
				00.03~		JOINT ASSY-INNER BALL	CT-H028
COUPE 07MY				90.12~		END ASSY-TIE ROD	CT-H013
				00.03~		JOINT ASSY-INNER BALL	CT-H028
COUPE 97MY	BETA		GASOLINE	94.07~01.11		END ASSY-TIE ROD	CT-H013

MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
	BETA		GASOLINE	95.03~98.04 98.04~01.10		JOINT ASSY-INNER BALL JOINT ASSY-INNER BALL	CT-H012 CT-H012
E-COUNTY 04EM	D4AL,D4DA,D4AF D4AL,D4DA,D4AF		DIESEL DIESEL	98.03~	L	END ASSY-TIE ROD LH	CT-H034
				98.03~	R	END ASSY-TIE ROD RH	CT-H035
				98.10~	R	END ASSY-TIE ROD RH	CT-H035
ECUUS				90.12~07.08		END ASSY-TIE ROD	CT-H013
ELANTRA				89.07~06.12		ROD ASSY-TIE	CT-H001
				89.07~95.03		BALL JOINT ASSY-INR	CT-H001
				90.11~92.06		END ASSY-TIE ROD	CT-H005
				90.12~		END ASSY-TIE ROD	CT-H013
				00.03~		JOINT ASSY-INNER BALL	CT-H028
				96.11~07.12		JOINT ASSY-INNER BALL	CT-H001
ELANTRA 00MY				96.06~		END ASSY-TIE ROD	CT-H013
				00.03~		JOINT ASSY-INNER BALL	CT-H028
ELANTRA 91MY	BETA		GASOLINE	90.11~92.06		END ASSY-TIE ROD	CT-H005
				91.04~01.08		END ASSY-TIE ROD	CT-H013
				92.04~93.07		ROD ASSY-TIE	CT-H001
ELANTRA 96MY	BETA BETA		GASOLINE GASOLINE	95.03~98.07		END ASSY-TIE ROD	CT-H013
				98.07~01.11		END ASSY-TIE ROD	CT-H013
				95.03~98.04		JOINT ASSY-INNER BALL	CT-H012
				98.04~01.10		JOINT ASSY-INNER BALL	CT-H012
E-MIGHTY	D4AL,D4DA,D4AF D4AL,D4DA,D4AF		DIESEL DIESEL	98.03~	L	END ASSY-TIE ROD LH	CT-H034
				98.10~	L	END ASSY-TIE ROD LH	CT-H034
				98.03~	R	END ASSY-TIE ROD RH	CT-H035
				98.10~	R	END ASSY-TIE ROD RH	CT-H035
EXCEL				89.07~06.12		ROD ASSY-TIE	CT-H001
				89.07~06.12		BALL JOINT ASSY-INR	CT-H001
				85.02~96.10		END ASSY-TIE ROD	CT-H007
				96.11~07.12		JOINT ASSY-INNER BALL	CT-H001
GALLOPER				91.10~	L	TIE ROD ASSY LH	CT-H008
				91.10~04.11		END ASSY-INR	CT-H010
				91.10~04.11		END ASSY-TIE ROD	CT-H009
GALLOPER INNOVATION				98.08~		END ASSY-INR	CT-H010
				98.08~		END ASSY-TIE ROD	CT-H009
				91.10~	L	TIE ROD ASSY LH	CT-H008
GALLOPER2				98.08~		END ASSY-INR	CT-H010
				98.08~		END ASSY-TIE ROD	CT-H009
				97.09~		TIE ROD ASSY LH	CT-H008
GETZ				99.03~		END ASSY-TIE ROD	CT-H013
GETZ05MY				99.03~		END ASSY-TIE ROD	CT-H013
GETZ07MY				05.06~		END ASSY-TIE ROD	CT-H013
GRACE				89.07~06.12		ROD ASSY-TIE	CT-H001
				89.07~06.12		BALL JOINT ASSY-INR	CT-H001
				87.01~07.12		END ASSY-TIE ROD	CT-H017
				96.11~07.12		JOINT ASSY-INNER BALL	CT-H001
GRANDEUR				90.12~07.08		END ASSY-TIE ROD	CT-H013
				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
GRANDEUR Q20				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
GRANDEUR TG				04.08~	L	END ASSY-TIE ROD LH	CT-H030
				04.08~	R	END ASSY-TIE ROD RH	CT-H031
				04.08~		JOINT ASSY-INNER BALL	CT-H038
GRANDEUR XG				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
GRANDEUR XG25				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
GRANDEUR XG250				98.09~	L	END ASSY-TIE ROD LH	CT-H003

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
GRANDEUR XG30				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
GRANDEUR XG300				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
H-1 02MY	D4BH,D4BH		DIESEL	01.07~07.12		END ASSY-TIE ROD	CT-H017
				01.07~07.12		ROD ASSY-TIE	CT-H001
H-1 04MY	D4BH,D4BH		DIESEL	01.07~07.12		END ASSY-TIE ROD	CT-H017
				01.07~07.12		ROD ASSY-TIE	CT-H001
H-1 98MY	D4BA,D4BB,D4BF,L4CS		DIESEL	96.03~06.12		END ASSY-TIE ROD	CT-H017
				96.11~07.05		ROD ASSY-TIE	CT-H001
H-100	D4BA,D4BF,L4CS		DIESEL	93.07~03.12		ROD ASSY-TIE	CT-H001
				98.08~03.12		ROD ASSY-TIE	CT-H001
	D4BA,D4BB,D4BF,L4CS		DIESEL	87.01~06.12		END ASSY-TIE ROD	CT-H017
				96.03~06.12		ROD ASSY-TIE	CT-H001
H-100 04MY				03.12~		END ASSY-TIE ROD	CT-H017
H-100 93MY				93.07~97.03		ROD ASSY-TIE END	CT-H014
					R	ROD ASSY-TIE END RH	CT-H015
H-100 94MY				93.07~97.03		ROD ASSY-TIE END	CT-H014
					R	ROD ASSY-TIE END RH	CT-H015
H-100 95MY				93.07~97.03		ROD ASSY-TIE END	CT-H014
					R	ROD ASSY-TIE END RH	CT-H015
H-100 96MY				93.07~97.03		ROD ASSY-TIE END	CT-H014
					R	ROD ASSY-TIE END RH	CT-H015
H-100 97MY				93.07~97.03		ROD ASSY-TIE END	CT-H014
					R	ROD ASSY-TIE END RH	CT-H015
H-100 98MY	D4BF,D4BH		DIESEL	96.11~07.05		END ASSY-TIE ROD	CT-H017
HD120 04EM				98.05~	L	END ASSY-TIE ROD LH	CT-H020
HD250				92.01~02.11	R	END ASSY-TIE ROD RH/98MY	CT-H021
					L	END ASSY-TIE ROD LH	CT-H025
					R	END ASSY-TIE ROD RH	CT-H026
					L	END ASSY-TIE ROD LH	CT-H025
HD350	D4AF,D4AE		DIESEL	92.01~02.11	L	END ASSY-TIE ROD LH	CT-H025
					R	END ASSY-TIE ROD RH	CT-H026
HD45				98.10~	L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H035
HD59	D4AF,D4AE		DIESEL	92.01~02.11	L	END ASSY-TIE ROD LH	CT-H025
					L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H026
					R	END ASSY-TIE ROD RH	CT-H035
HD5T TRUCK				93.01~	L	END ASSY-TIE ROD LH(5T,OLD)	CT-H022
					L	END ASSY-TIE ROD LH	CT-H020
					R	END ASSY-TIE ROD RH(5T,OLD)	CT-H023
					R	END ASSY-TIE ROD RH/98MY	CT-H021
HD60	D4AF,D4AE		DIESEL	92.01~02.11	L	END ASSY-TIE ROD LH	CT-H025
					L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H026
					R	END ASSY-TIE ROD RH	CT-H035
HD65	D4AF,D4AE		DIESEL	92.01~02.11	L	END ASSY-TIE ROD LH	CT-H025
					L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H026
					R	END ASSY-TIE ROD RH	CT-H035
HD72				98.10~	L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H035
HD72 98~04MY	D4AF,D4AE		DIESEL	92.01~02.11	L	END ASSY-TIE ROD LH	CT-H025
					L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H026
					R	END ASSY-TIE ROD RH	CT-H035
HD78 04EM				98.10~	L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H035

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.	
LAVITA				96.06~		END ASSY-TIE ROD	CT-H013	
LAVITA 08MY				01.03~		JOINT ASSY-INNER BALL	CT-H019	
LAVITA 09MY				01.03~		JOINT ASSY-INNER BALL	CT-H019	
LIBERO	D4BF,D4BH D4BH,D4BH D4BA,D4BB,D4BF,L4CS		DIESEL	96.11~07.05		END ASSY-TIE ROD	CT-H017	
				01.07~07.12		END ASSY-TIE ROD	CT-H017	
				96.03~06.12		END ASSY-TIE ROD	CT-H017	
				87.01~06.12		END ASSY-TIE ROD	CT-H017	
MATRIX				96.06~		END ASSY-TIE ROD	CT-H013	
				01.03~		JOINT ASSY-INNER BALL	CT-H019	
MATRIX08MY				01.03~		JOINT ASSY-INNER BALL	CT-H019	
MATRIX09MY				01.03~		JOINT ASSY-INNER BALL	CT-H019	
MEGA TRUCK				98.05~	L	END ASSY-TIE ROD LH	CT-H020	
MEGA TRUCK				97.12~	R	END ASSY-TIE ROD RH/98MY	CT-H021	
MIGHTY	D4AF,D4AE		DIESEL	92.01~04.01	L	END ASSY-TIE ROD LH	CT-H025	
				92.01~02.11	R	END ASSY-TIE ROD RH	CT-H026	
				04.01~04.01	R	END ASSY-TIE ROD RH	CT-H026	
MIGHTY2	D4AL,D4DA,D4AF		DIESEL	92.01~04.01	L	END ASSY-TIE ROD LH	CT-H025	
				98.03~	L	END ASSY-TIE ROD LH	CT-H034	
				98.10~	L	END ASSY-TIE ROD LH	CT-H034	
	D4AF,D4AE D4AL,D4DA,D4AF		DIESEL	DIESEL	92.01~02.11	R	END ASSY-TIE ROD RH	CT-H026
					98.10~	R	END ASSY-TIE ROD RH	CT-H035
						R	END ASSY-TIE ROD RH	CT-H035
					04.01~04.01	R	END ASSY-TIE ROD RH	CT-H026
MX ATOS				97.08~07.01		END ASSY-TIE ROD	CT-H002	
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029	
NEW SPORTAGE				04.03~	L	END ASSY-TIE ROD LH	CT-H032	
				04.03~	R	END ASSY-TIE ROD RH	CT-H033	
PORTER	D4BA,D4BF,L4CS D4BA,D4BB,L4CS D4BB,D4BF,L4CS D4BF,D4BH D4BH,D4BH D4BA,D4BB,D4BF,L4CS D4BB,D4BF,L4CS,D4BH D4BH,D4BH D4BA,D4BB,D4BF,L4CS	2.4	DIESEL	98.08~03.12		ROD ASSY-TIE	CT-H001	
				89.07~95.03		BALL JOINT ASSY-INR	CT-H001	
				93.07~03.12		ROD ASSY-TIE	CT-H001	
				96.03~99.03		ROD ASSY-TIE	CT-H001	
				96.03~06.12		ROD ASSY-TIE	CT-H001	
				00.03~06.12		END ASSY-TIE ROD	CT-H017	
				96.11~07.05		END ASSY-TIE ROD	CT-H017	
				01.07~07.12		END ASSY-TIE ROD	CT-H017	
				87.01~96.02		ROD ASSY-TIE	CT-H016	
				96.03~06.12		END ASSY-TIE ROD	CT-H017	
				87.01~04.01	L	ROD ASSY-TIE END LH	CT-H014	
				93.07~97.03		ROD ASSY-TIE END	CT-H014	
				87.01~04.01		ROD ASSY-TIE END	CT-H015	
					R	ROD ASSY-TIE END RH	CT-H015	
				96.11~07.05		JOINT ASSY-INNER BALL	CT-H001	
01.07~07.12		JOINT ASSY-INNER BALL	CT-H001					
96.03~06.12		BALL JOINT ASSY-INR	CT-H001					
87.01~		END ASSY-TIE ROD	CT-H017					
SANTA FE				99.03~		END ASSY-TIE ROD	CT-H013	
SANTRO				97.08~07.01		END ASSY-TIE ROD	CT-H002	
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029	
SANTRO 06MY				97.08~07.01		END ASSY-TIE ROD	CT-H002	
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029	
SANTRO 99MY				97.08~07.01		END ASSY-TIE ROD	CT-H002	
				97.08~07.01		BALL JOINT ASSY-INR	CT-H029	
SCOUBE				89.07~95.03		BALL JOINT ASSY-INR	CT-H001	
				85.11~94.08		END ASSY-TIE ROD	CT-H007	
				89.07~95.03		ROD ASSY-TIE	CT-H001	
SONATA				88.06~93.09		END ASSY-TIE ROD	CT-H018	
				98.09~	L	END ASSY-TIE ROD LH	CT-H003	
				98.09~	R	END ASSY-TIE ROD RH	CT-H004	
				93.03~07.06		JOINT ASSY-INNER BALL	CT-H019	
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024	
				98.06~93.09		BALL JOINT ASSY-INR	CT-H037	
				01.03~		BALL JOINT ASSY-INR	CT-H019	

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.		
SONATA 02MY				98.09~	L	END ASSY-TIE ROD LH	CT-H003		
				98.09~	R	END ASSY-TIE ROD RH	CT-H004		
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024		
SONATA 91MY				88.06~93.09		END ASSY-TIE ROD	CT-H018		
				98.06~93.09		BALL JOINT ASSY-INR	CT-H037		
SONATA 94MY				93.03~98.06		JOINT ASSY-INNER BALL	CT-H019		
SONATA 99MY				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024		
				98.03~99.01	L	END ASSY-TIE ROD LH	CT-H003		
				98.03~99.01	R	END ASSY-TIE ROD RH	CT-H004		
SONATA EF				98.09~	L	END ASSY-TIE ROD LH	CT-H003		
				98.09~	R	END ASSY-TIE ROD RH	CT-H004		
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024		
SONATA NF				04.08~	L	END ASSY-TIE ROD LH	CT-H030		
				04.08~	R	END ASSY-TIE ROD RH	CT-H031		
				04.08~		JOINT ASSY-INNER BALL	CT-H038		
SONATA NF 04MY				04.08~	L	END ASSY-TIE ROD LH	CT-H030		
				04.08~	R	END ASSY-TIE ROD RH	CT-H031		
				04.08~		JOINT ASSY-INNER BALL	CT-H038		
SONATA NF 08MY				07.04~	L	END ASSY-TIE ROD LH	CT-H030		
				07.04~		JOINT ASSY-INNER BALL	CT-H038		
SONATA NF 09MY				07.04~	L	END ASSY-TIE ROD LH	CT-H030		
				07.04~		JOINT ASSY-INNER BALL	CT-H038		
STAREX				89.07~03.12		ROD ASSY-TIE	CT-H001		
				89.07~95.03		BALL JOINT ASSY-INR	CT-H001		
				D4BA,D4BF,L4CS	DIESEL	93.07~03.12		ROD ASSY-TIE	CT-H001
				D4BA,D4BB,L4CS	DIESEL	96.03~99.03		ROD ASSY-TIE	CT-H001
						00.03~06.12		END ASSY-TIE ROD	CT-H017
				D4BF,D4BH	DIESEL	96.11~07.05		END ASSY-TIE ROD	CT-H017
				D4BH,D4BH	DIESEL	01.07~07.12		END ASSY-TIE ROD	CT-H017
				D4BA,D4BB,D4BF,L4CS	DIESEL	96.03~06.12		END ASSY-TIE ROD	CT-H017
				D4BB,D4BF,L4CS,D4BH	DIESEL	96.11~07.05		JOINT ASSY-INNER BALL	CT-H001
				D4BH,D4BH	DIESEL	01.07~07.12		JOINT ASSY-INNER BALL	CT-H001
						97.10~97.10		JOINT ASSY-INNER BALL [EXPORT]	CT-H036
				D4BA,D4BB,D4BF,L4CS	DIESEL	96.03~06.12		ROD ASSY-TIE	CT-H001
STAREX 02MY				D4BH,D4BH	DIESEL	01.07~07.12	END ASSY-TIE ROD	CT-H017	
				D4BH,D4BH	DIESEL	01.07~07.12		JOINT ASSY-INNER BALL	CT-H001
STAREX 97MY				D4BF,D4BH	DIESEL	96.11~07.05	END ASSY-TIE ROD	CT-H017	
				D4BA,D4BB,D4BF,L4CS	DIESEL	96.03~06.12		END ASSY-TIE ROD	CT-H017
				D4BB,D4BF,L4CS,D4BH	DIESEL	96.11~07.05		JOINT ASSY-INNER BALL	CT-H001
STELLA (NEW)				85.02~96.10		END ASSY-TIE ROD	CT-H007		
TB(JAPAN)				99.03~		END ASSY-TIE ROD	CT-H013		
TIBURON				90.21~07.08		END ASSY-TIE ROD	CT-H013		
				BETA	GASOLINE	91.04~01.11		END ASSY-TIE ROD	CT-H013
				BETA	GASOLINE	95.03~98.04		JOINT ASSY-INNER BALL	CT-H012
						98.04~01.10		JOINT ASSY-INNER BALL	CT-H012
TRAJET				99.03~		END ASSY-TIE ROD	CT-H013		
				99.10~07.06		JOINT ASSY-INNER BALL	CT-H019		
TRAJET XG				93.03~07.06		JOINT ASSY-INNER BALL	CT-H019		
TUCSON				04.03~	L	END ASSY-TIE ROD LH	CT-H032		
				04.03~	R	END ASSY-TIE ROD RH	CT-H033		
				04.03~		JOINT ASSY-INNER BALL	CT-H039		
TUSCANI				00.03~		JOINT ASSY-INNER BALL	CT-H028		
VERNA				99.06~07.02		BALL JOINT ASSY-INR	CT-H027		
				90.12~07.08		END ASSY-TIE ROD	CT-H013		
				BETA	GASOLINE	91.04~01.11		END ASSY-TIE ROD	CT-H013

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
KIA							
AVELLA	B3,B5 B3,B5		GASOLINE GASOLINE	04.01~		END ASSY-TIE ROD	CT-K015
				98.05~00.09		JOINT-BALL,IN.	CT-K028
				99.11~02.09		JOINT BALL-IN.	CT-K028
				94.03~05.06		JOINT-BALL,OUTER	CT-K015
BESTA	FE		DIESEL	91.01~99.12		BALL JOINT-END	CT-K001
				92.07~00.07		JOINT-BALL RACK END(P/S 2.7)	CT-K002
				95.10~00.11		BALL JOINT END	CT-K008
				00.01~		BALL JOINT END	CT-K008
	FE		DIESEL	95.10~01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01~05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
				92.07~00.07		JOINT-BALL,OUTER	CT-K001
				92.07~00.07		JOINT BALL BACK END	CT-K002
BONGO FRONTIER 1T				97.04~		B/J ASSY-INNER	CT-K016
				91.01~00.07		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10~01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01~05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
BONGO(POWER)				92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				~94.12	R	BALL JOINT	CT-K017
				~94.12	L	BALL JOINT	CT-K017
BONGO(WIDE)				91.01~00.07		BALL JOINT-END	CT-K001
				92.07~00.07		JOINT-BALL RACK END(P/S 2.7)	CT-K002
BONGO3				95.10~		BALL JOINT END	CT-K008
				95.10~01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01~05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
CAPITAL	FE,F8		GASOLINE	92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				~94.12	R	BALL JOINT	CT-K017
				~94.12	L	BALL JOINT	CT-K017
CARENS				93.06~06.08		JOINT-BALL	CT-K007
CARENS 00MY				92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
CARENS2 00MY				97.02~04.03		BALL JOINT-INNER	CT-K502
CARENS2 02MY				02.04~06.08		BALL JOINT-INNER	CT-K502
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
CARNIVAL	J3,K5 J3,K5 J3,K5 J3,K5 J3,K5 J3,K5		DIESEL	98.01~10.01	L	TIE ROD END ASSY LH	CT-K004
				98.06~00.05	R	BALL JOINT-INNER.RH	CT-K020
				98.06~99.08	R	BALL JOINT-INNER.RH	CT-K022
				98.06~00.05	L	BALL JOINT-INNER.LH(OLD)	CT-K019
				98.06~10.01	L	BALL JOINT-IN LH	CT-K021
				98.01~10.01	R	TIE ROD END.RH(=→MARKING RH)	CT-K003
CARSTAR				90.12~07.08		END ASSY-TIE ROD	CT-H013
CERATO	BETA		GASOLINE	90.12~07.08		END ASSY-TIE ROD	CT-H013
				91.04~01.11		END ASSY-TIE ROD	CT-H013
				00.03~		JOINT ASSY-INNER BALL	CT-H028
CERES	SC SC SC SC		DIESEL	99.02~05.04		JOINT-BALL	CT-K041
				99.02~05.04		JOINT-BALL,OUTER(D/R)	CT-K040
				99.02~05.04	R	ROD ASSY-TIE.RH	CT-K043
				99.02~05.04	L	TIE ROD.END LH	CT-K042
CLARUS				95.10~00.10		BALL JOINT - INNER	CT-K014
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
CONCORD	FE,F8		GASOLINE	92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				~94.12	R	BALL JOINT(RH)(1B 70)	CT-K017
				~94.12	L	BALL JOINT.LH(1B:70)	CT-K017
COSMOS	K6,K7 K6,K7		DIESEL	95.04~03.09	R	END TIE ROD RH J	CT-K013
				95.04~03.09	L	END TIE ROD LH J	CT-K012
				93.12~99.12		END TIE ROD RH J	CT-K013
				93.12~99.12		END TIE ROD LH J	CT-K012
COSMOS (NEW)	K6,K7 K6,K7		DIESEL	95.04~03.09		END TIE ROD RH J	CT-K013
				95.04~03.09	L	END TIE ROD LH J	CT-K012

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
CREDOS				93.12-99.12		END TIE ROD LH J	CT-K012
				93.06-00.10		BALL JOINT - INNER	CT-K014
				93.06-97.12		JOINT-BALL	CT-K007
				97.02-06.08		BALL JOINT-INNER	CT-K502
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
CREDOS2				93.06-00.10		BALL JOINT - INNER	CT-K014
				93.06-97.12		JOINT-BALL	CT-K007
				97.02-06.08		BALL JOINT-INNER	CT-K502
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
				97.04~		B/J ASSY-INNER	CT-K016
FESTIVA				90.02-01.12		BALL JOINT -TIE ROD(MB092)	CT-K010
				90.02-01.12		INNER B/J KIT	CT-K009
FRONTIER				97.04~		B/J ASSY-INNER	CT-K016
H-100	D4BA,D4BF,L4CS		DIESEL	93.07-97.10		ROD ASSY-TIE	CT-H001
K2500				97.04~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10-01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01-05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
K2700				97.04~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10-01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01-05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
K2700±				97.04~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10-01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01-05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
K3000				97.04~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10-01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01-05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
K3000±				97.04~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				95.10~		BALL JOINT END	CT-K008
				95.10-01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01-05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
K3000S				01.03~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				00.01~		BALL JOINT END	CT-K008
K4000S				01.03~		B/J ASSY-INNER	CT-K016
				92.07~		BALL JOINT-END	CT-K001
				00.01~		BALL JOINT END	CT-K008
MENTOR	B5,TE		GASOLINE	97.02-04.03		BALL JOINT-INNER	CT-K502
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
MENTOR2	B5,TE		GASOLINE	97.02-04.03		BALL JOINT-INNER	CT-K502
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
MORNING				04.01-06.12		JOINT ASSY-INNER BALL	CT-K031
				94.03-05.06		END ASSY-TIE ROD	CT-K015
OPIRUS				98.09~	L	END ASSY-TIE ROD LH	CT-H003
				98.09~	R	END ASSY-TIE ROD RH	CT-H004
				98.03-99.01		END ASSY-TIE ROD LH	CT-H003
				98.03-99.01		END ASSY-TIE ROD RH	CT-H004
OPTIMA				98.03~	L	END ASSY-TIE ROD LH	CT-H003
				98.03~	R	END ASSY-TIE ROD RH	CT-H004
				98.03-06.12		JOINT ASSY-INNER BALL	CT-H024
PAMAX	D4AL,D4DA,D4AF		DIESEL	98.03~	L	END ASSY-TIE ROD LH	CT-H034
				98.10~	L	END ASSY-TIE ROD LH	CT-H034
					R	END ASSY-TIE ROD RH	CT-H035
PICANTO 04MY				04.01~		END ASSY-TIE ROD	CT-K015
				04.01-06.12		JOINT ASSY-INNER BALL	CT-K031

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
PICANTO 08MY				04.01~		END ASSY-TIE ROD	CT-K015
POTENTIA		2.9		92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				~94.12		BALL JOINT(RH)(1B 70)	CT-K017
				~94.12		BALL JOINT.LH(1B:70)	CT-K017
POTENTIA (NEW)				92.04~05.04		END ASSY-TIE ROD(CP,PTN FE F2)	CT-K017
				~94.12		BALL JOINT(RH)(1B 70)	CT-K017
				~94.12		BALL JOINT.LH(1B:70)	CT-K017
PREGIO				95.10~00.11		BALL JOINT END	CT-K008
				00.01~		BALL JOINT-END	CT-K008
				95.10~01.04		BALL JOINT INNER (M17*1.0)	CT-K023
				00.01~05.10		BALL JOINT- INNER (MANDO)(M18*1.5)	CT-K018
PRIDE				85.01~01.12		BALL JOINT -TIE ROD(MB092)	CT-K010
				90.02~05.04		INNER B/J KIT	CT-K009
				92.11~99.07		JOINT-BALL	CT-K010
				92.11~05.04		JOINT,BALL	CT-K009
PRIDE (JB)				05.02~	L	END ASSY-TIE ROD LH	CT-K025
				05.02~	R	END ASSY-TIE ROD RH	CT-K024
REGAL				98.03~	L	END ASSY-TIE ROD LH	CT-H003
				98.03~	R	END ASSY-TIE ROD RH	CT-H004
				98.03~06.12		JOINT ASSY-INNER BALL	CT-H024
RETONA	RF-TCI,HW,FE		DIESEL	97.11~99.01	L	TIE ROD ASS Y LH	CT-K026
				94.11~03.06	L	TIE ROD ASS Y LH	CT-K026
				97.11~99.01	R	TIE ROD ASS Y RH	CT-K027
	RF-TCI,HW,FE		DIESEL	94.11~03.06	R	TIE ROD ASS Y RH	CT-K027
RHINO				93.12~03.09	R	END TIE ROD RH J	CT-K013
				93.12~03.09	L	END TIE ROD LH J	CT-K012
RIO				04.01~		END ASSY-TIE ROD	CT-K015
				99.11~02.09		JOINT-BALL,IN.	CT-K028
						JOINT BALL-IN.	CT-K028
				94.03~05.06		JOINT-BALL,OUTER	CT-K015
RIO 00MY						JOINT-BALL,IN.	CT-K028
				99.11~02.09		JOINT BALL-IN.	CT-K028
				94.03~05.06		JOINT-BALL,OUTER	CT-K015
RIO 05MY				05.02~	L	END ASSY-TIE ROD LH	CT-K025
				05.02~	R	END ASSY-TIE ROD RH	CT-K024
SEDONA 98MY	J3,K5		DIESEL	98.01~10.01	L	TIE ROD END ASSY LH	CT-K004
	J3,K5		DIESEL	98.06~00.05	R	BALL JOINT-INNER.RH	CT-K020
	J3,K5		DIESEL	98.06~99.08	R	BALL JOINT-INNER.RH	CT-K022
	J3,K5		DIESEL	98.06~00.05	L	BALL JOINT-INNER.LH(OLD)	CT-K019
	J3,K5		DIESEL	98.06~10.01	L	BALL JOINT-IN LH	CT-K021
	J3,K5		DIESEL	98.01~10.01	R	TIE ROD END.RH(=→MARKING RH)	CT-K003
SEPHIA	B5		GASOLINE	93.06~97.12		JOINT-BALL	CT-K007
	B5,TE		GASOLINE	96.11~98.05		BALL JOINT - INNER	CT-K014
				97.02~04.03		BALL JOINT-INNER	CT-K502
				02.04~06.08		BALL JOINT-INNER	CT-K502
				93.06~00.10		BALL JOINT - INNER	CT-K014
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
SEPHIA2	B5		GASOLINE	93.06~97.12		JOINT-BALL	CT-K007
	B5,TE		GASOLINE	96.11~98.05		BALL JOINT - INNER	CT-K014
				97.02~04.03		BALL JOINT-INNER	CT-K502
				02.04~06.08		BALL JOINT-INNER	CT-K502
				93.06~00.10		BALL JOINT - INNER	CT-K014
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
SHUMA	B5,TE		GASOLINE	93.06~97.12		JOINT-BALL	CT-K007
				97.02~04.03		BALL JOINT-INNER	CT-K502
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
SHUMA2	B5,TE		GASOLINE	97.02~04.03		BALL JOINT-INNER	CT-K502
				94.11~06.08		JOINT ASSY- OUTER BALL	CT-K007
SORENTO				02.01~09.08	L	TIE ROD END ASSY.LH	CT-K029
				02.01~09.08	R	TIE ROD END ASSY.RH	CT-K030
				02.01~		INNER BALL JOINT ASSY TUBE	CT-K032
				02.01~		INNER BALL JOINT ASSY-HSG	CT-K032

MODEL	ENGNIE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
SORENTO 03MY				02.01-09.08	L	TIE ROD END ASSY.LH	CT-K029
				02.01-09.08	R	TIE ROD END ASSY.RH	CT-K030
SORENTO 06MY				02.01-09.08	L	TIE ROD END ASSY.LH	CT-K029
				02.01-09.08	R	TIE ROD END ASSY.RH	CT-K030
SPECTRA	B5,TE		GASOLINE	93.06-97.12		JOINT-BALL	CT-K007
				97.02-04.03		BALL JOINT-INNER	CT-K502
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
SPECTRA WING				93.06-97.12		JOINT-BALL	CT-K007
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
SPORTAGE	RF-TCI,HW,FE		DIESEL	97.11-99.01	L	TIE ROD ASS Y LH	CT-K026
				94.11-03.06	L	TIE ROD ASS Y LH	CT-K026
				97.11-99.01	R	TIE ROD ASS Y RH	CT-K027
	RF-TCI,HW,FE		DIESEL	94.11-03.06	R	TIE ROD ASS Y RH	CT-K027
				93.06-97.12		JOINT-BALL	CT-K007
				94.11-06.08		JOINT ASSY- OUTER BALL	CT-K007
SPORTAGE (NEW)				04.03~		JOINT ASSY-INNER BALL	CT-H039
TOPIC				91.01-00.07		BALL JOINT-END	CT-K001
TRADE				95.03-00.09	R	JOINT-BALL RH	CT-K034
				95.03-00.09	L	JOINT-BALL LH	CT-K033
VISTO				97.08-07.01		END ASSY-TIE ROD	CT-H002
				97.08-07.01		BALL JOINT ASSY-INR	CT-H029

GM DAEWOO

CIELO					R	END HEAD,TIE ROD,RH	CT-D003
					L	END HEAD,TIE ROD,LH	CT-D004
						ROD A-TIE	CT-D004
						ROD A-TIE	CT-D003
						END-TIE ROD	CT-D004
					L	END-TIE ROD	CT-D003
					L	ROD-TIE INNER	CT-D018
					L	ROD-TIE,OUTER	CT-D004
					R	ROD-TIE,OUTER	CT-D003
					R	ROD-TIE INNER	CT-D019
					L	ROD A-TIE LH	CT-D003
					R	ROD A-TIE RH	CT-D004
					L	HEAD END A-TIE ROD.LH	CT-D003
					R	HEAD END A-TIE ROD.RH	CT-D004
DAMAS/LABO					R	END COMP-STEERING TIE-ROD	CT-D002
					L	END COMP-STEERING TIE-ROD	CT-D001
ESPERO						HEAD END A-TIE ROD	CT-D004
					R	HEAD END A-TIE ROD	CT-D003
					L	HEAD END A-TIE ROD	CT-D004
						HEAD END A-TIE ROD	CT-D003
						END-TIE ROD	CT-D004
					L	END-TIE ROD	CT-D003
					L	ROD-TIE,OUTER	CT-D004
					R	ROD-TIE,OUTER	CT-D003
					L	ROD A-TIE	CT-D003
					R	ROD A-TIE	CT-D004
					L	HEAD END A-TIE ROD	CT-D003
					R	HEAD END A-TIE ROD	CT-D004
KALOS(T200)					L	ROD A-TIE	CT-D010
					L	END-TIE ROD	CT-D010
					R	ROD A-TIE	CT-D011
						ROD A-TIE	CT-D010
						ROD A-TIE	CT-D011
LACETTI(J200)	FAM1,FAM2				L	RACK END	CT-D013
					L	ROD-TIE END	CT-D014

MODEL	ENGNE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
LANOS(T100)	FAM1,FAM2				R	ROD-TIE END	CT-D015
						RACK END	CT-D012
						ROD A-TIE	CT-D004
						ROD A-TIE	CT-D003
					R	HEAD END A-TIE ROD	CT-D003
					L	HEAD END A-TIE ROD	CT-D004
						HEAD END A-TIE ROD	CT-D003
						HEAD END A-TIE ROD	CT-D004
						ROD-TIE, OUTER	CT-D004
						ROD-TIE, OUTER	CT-D003
					L	ROD-TIE END	CT-D018
					L	HEAD END A-TIE ROD	CT-D003
R	HEAD END A-TIE ROD	CT-D004					
LEGANZA(V100)					R/L	ROD-TIE END	CT-D005
LEMAN	FAM1,FAM2					ROD-TIE END	CT-D005
					R	ROD A-TIE	CT-D004
					R	END HEAD,TIE ROD,RH	CT-D003
					L	END HEAD,TIE ROD,LH	CT-D004
						ROD A-TIE	CT-D003
						END-TIE ROD	CT-D004
					L	END-TIE ROD	CT-D003
						ROD-TIE, OUTER	CT-D004
						ROD-TIE, OUTER	CT-D003
					L	ROD-TIE INNER	CT-D018
					R	ROD-TIE INNER	CT-D019
					L	ROD A-TIE LH	CT-D003
					R	ROD A-TIE RH	CT-D004
L	HEAD END A-TIE ROD.LH	CT-D003					
R	HEAD END A-TIE ROD.RH	CT-D004					
MAGNUS(V200)					R/L	ROD KIT-TIE.INR	CT-D023
	FAM1,FAM2				R/L	ROD-TIE END	CT-D005
						ROD-TIE END	CT-D005
MATIZ(M100)						END COMP-STEERING TIE-ROD	CT-D006
						END COMP-STEERING TIE ROD	CT-D006
						ROD A-INNER TIE	CT-D009
						ROD A-OUTER TIE	CT-D006
						INR-BALL JOINT ASSY	CT-D016
NUBIRA(J100)					R/L	ROD-TIE END	CT-D005
PRINCE					R/L	ROD-TIE END	CT-D005
						ROD KIT-TIE,INR	CT-D008
						TIE ROD END	CT-D005
REZZO(U100)	FAM2				R/L	TIE ROD END	CT-D005
	FAM2				L	ROD KIT-TIE,INR	CT-D017
					R	ROD-TIE END	CT-D021
TICO	FAM2					ROD-TIE END	CT-D022
						END COMP-STEERING TIE ROD	CT-D006
						TIE-ROD COMP-STEERING	CT-D025

SSANGYONG

ISTANA	OM661,OM662		DIESEL			B/JOINT ASSY-KIT OUT	CT-S002
MUSSO	OM661,OM662		DIESEL			B/JOINT ASSY-KIT INR	CT-S003
	OM661,OM662,E32		DIESEL	96.04~00.03 93.08~		END-SUSP UPR FRT	CT-S005
NEW KORANDO	OM661,OM662,E32		DIESEL			END ASSY-FRT SUSPENSION U	CT-S005
						BOOT-UPR ARM END (W/WIRE)	CT-S005
						END ASSY-TIE ROD	CT-S001
						RACK END	CT-D024
						END-SUSP UPR FRT	CT-S005
						END ASSY-FRT SUSPENSION U	CT-S005
						BOOT-UPR ARM END (W/WIRE)	CT-S005



MODEL	ENGINE	CAPA(L)	FUEL	YEAR FR.-TO	LOCATION	PART NAME	FACTORY NO.
-------	--------	---------	------	-------------	----------	-----------	-------------

SAMSUNG

SV110(YAMOUZINE)	TD27		DIESEL		L	ROD ASSY-TIE	CT-U001
	TD27		DIESEL		R	ROD ASSY-TIE	CT-U002